






































































































Original	Replacement	Original	Replacement
 Power	 Power	 Prog-	 Ch -
 Open/Close	 Eject	 Vol+	 Vol +
 HDD	 Media	 Vol-	 Vol -
 DVD	 Smart	 O))	 Dual
 1	 1	 [...]	 Subt
 2	 2	 Camera	 Yellow
 3	 3	 Tv/DVD	 TV/R
 4	 4	 Timer	 Shift + AV
 5	 5	 Display	 Info
 6	 6	 Time/Text	 Text
 7	 7	 System Menu	 D. Menu
 8	 8	 Title List	 Blue
 9	 9	 Tools	 Options
 0	 0	 Return	 Back
 Clear	 Exit	 Up	 Up
 Set	 Red	 Down	 Down
 Prog+	 Ch +	 Right	 Right





































































Original	Replacement
 Power	 Power
 Tv/DVD	 TV/R
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/--	 Shift + Guide
 Prog+	 Ch +
 Prog-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -

Original	Replacement
 Text	 Text
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Guide	 Guide
 [i+]	 Info
 Fav	 Pre Ch
 Up	 Up
 Left	 Left
 Enter	 Ok
 Right	 Right
 Down	 Down























































Original	Replacement	Original	Replacement
 Power	 Power	 Prog-	 Ch -
 Open/Close	 Eject	 Vol+	 Vol +
 HDD	 Media	 Vol-	 Vol -
 DVD	 Smart	 O))	 Dual
 1	 1	 [...]	 Subt
 2	 2	 Camera	 Yellow
 3	 3	 Tv/DVD	 TV/R
 4	 4	 Timer	 Shift + AV
 5	 5	 Display	 Info
 6	 6	 Time/Text	 Text
 7	 7	 System Menu	 D. Menu
 8	 8	 Title List	 Blue
 9	 9	 Tools	 Options
 0	 0	 Return	 Back
 Clear	 Exit	 Up	 Up
 Set	 Red	 Down	 Down
 Prog+	 Ch +	 Right	 Right





Original	Replacement	Original	Replacement
 Power	 Power	 Prog-	 Ch -
 Open/Close	 Eject	 Vol+	 Vol +
 HDD	 Media	 Vol-	 Vol -
 DVD	 Smart	 O))	 Dual
 1	 1	 [...]	 Subt
 2	 2	 Camera	 Yellow
 3	 3	 Tv/DVD	 TV/R
 4	 4	 Timer	 Shift + AV
 5	 5	 Display	 Info
 6	 6	 Time/Text	 Text
 7	 7	 System Menu	 D. Menu
 8	 8	 Title List	 Blue
 9	 9	 Tools	 Options
 0	 0	 Cursor Mode	 Green
 Clear	 Exit	 Return	 Back
 Set	 Red	 Up	 Up
 Prog+	 Ch +	 Down	 Down





Original	Replacement
	Right
	Left
	Ok
	+ Shift + Menu
	+ Shift + Left
	+ Shift + Right
	Menu
	I<<
	<</>
	I>>>
	Play
	Pause
	Stop
	Rec
	+ Shift + Pause
	+ Shift + Stop

Original	Replacement
	+ Shift + Rec
	AV
	Format
	Pre Ch
	List
	Guide

