























































Original		Replacement		Original		Replacement	
	Power		Power		Next		>>
	Open / Close		Eject		Mute		Mute
	Subtitle		Subt		Return		Back
	Top Menu		D. Menu		Dimmer		Shift + Mute
	Audio		Dual		P-Scan		Smart
	Angle		3D		Up		Up
	Menu		Menu		Left		Left
	A-B		Shift + Text		Enter		Ok
	Search		TV/R		Right		Right
	Repeat		Text		Down		Down
	[M] ↔ □		Media		Display		Info
	Play		Play		Setup		Options
	Stop		Stop		1		1
	Pause / Step		Pause		2		2
	Rew.		<<		3		3
	F.F.		>>		4		4
	Previous		I<<		5		5



