

































Original	Replacement	Original	Replacement
	Power		Vol-
			Vol+
	Back		CH- / Page-
	Menu		Red / Netflix / Search
	Up		Green / APP / Repeat
	Left		Yellow / YouTube / Repeat
	Ok		Blue / Prime Video / Random
	Right		Mute / Dimmer
	Down		Rec / Rec Mode
	Exit		Source
	Stop		Option
	Smart Tv		Subt.
	Skip Prev.		IPTV
	Play		Eco / Search
	Pause		Guide-Popup
	Skip Next		Ch.List
	Ch+		Info










Original	Replacement	Original	Replacement
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	Disc Menu		D.Menu / Top
	0		0
	Text / Media		Text / Goto
	Sound		Sound / Title
	Repeat		Zoom / Size
			Shift + Green / APP /
			
			

Original	Replacement





Original	Replacement	Original	Replacement
	Power		Power
	(•J)		TV/Radio /
	Back		Back / Return
	Menu		Menu / Home
	Up		Up
	Left		Left
	Ok		OK
	Right		Right
	Down		Down
	Exit		Exit / Cancel / Clear
	Stop		Stop / Hold
	Smart Tv		Smart / List
	Skip Prev.		I<< / Preset-
	Play		Play / Slow
	Pause		Pause / Step / Freeze
	Skip Next		>>I / Preset+
	Ch+		CH+ / Page+
	Vol-		Vol-
	Vol+		Vol+
	Ch-		CH- / Page-
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue/00/Lang.		Blue / Prime Video / Random
	Mute		Mute / Dimmer
	Rec		Rec / Rec Mode
	Source		AV / Input / RDS
	Option		Setup / OPT /
	Subt.		Subtitle / EQ
	Iptv		Display / Media
	Eco/Search		Fav / Marker / PC
	Guide/ Popup		Guide / EPG / -/--
	Ch.List		Shift + Smart / List
	Info		Info / Angle





Original		Replacement	
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
DISC MENU	Disc Menu	TOP MENU D.MENU	D.Menu / Top
0	0	HDMI - BAT 0	0
TEXT MEDIA CENTER	Text/ Media	GOTO TEXT	Text / Goto
SOUND	Sound	TITLE SOUND	Sound / Title
REPEAT	Repeat	SIZE ZOOM	Zoom / Size
		SHIFT + APP	Shift + Green / APP /

Original	Replacement

