















Original		Replacement		Original		Replacement	
	Power		Power		Up		Up
	1		1		Down		Down
	2		2		Right		Right
	3		3		Left		Left
	4		4		OK		Ok
	5		5		Red		Red
	6		6		Green		Green
	7		7		Yellow		Yellow
	8		8		Blue		Blue
	9		9		Vol+		Vol +
	0		0		Vol-		Vol -
	List		List		Mute		Mute
	OPT		Options		CH+		Ch +
	Back		Back		CH-		Ch -
	Exit		Exit		Menu		Menu
	EPG		Guide		TXT		Text
	Info		Info		TV/S		TV/R





Original		Replacement		Original		Replacement	
	*		Pre Ch				
	APP		Media				
	Disp		Shift + Info				

