


















































Original	Replacement
	 Power
	 Source
	 [=]
	 I-II
	 [...]
	 Red
	 Green
	 Yellow
	 Blue
	 Menu
	 EPG
	 Up
	 <<
	 Play
	 Pause
	 >>
	 Down

Original	Replacement
	 Option
	 [i+]
	 Vol+
	 Stop
	 Page+
	 Vol-
	 Mute
	 Page-
	 1
	 2
	 3
	 FAV
	 4
	 5
	 6
	 J/Slideshow
	 7





	Original	Replacement		Original	Replacement
	ROTATE	Display / Media			
	SETUP	Setup / OPT /			
		Picture / Format			
	ZOOM	Zoom / Size			

