



























Original	Replacement
 Power	 Power
 Input 1	 Shift + 1
 Input 2	 Shift + 2
 Input 3	 Shift + 3
 Input 4	 Shift + 4
 Input 5	 Shift + 5
 PC	 Shift + Fav / Marker / PC
 HMG	 Shift + 6
 [i+]/Timer/Info	 Sleep / Timer
 [i+]/Timer/Info	 Info / Angle
 [TV]	 Shift + Red / Netflix /
 [TV]	 Shift + Yellow / YouTube /
 [TV]	 Shift + Green / APP /
 CTRL HDMI	 Picture / Format
 1	 1
 2	 2
 3	 3

Original	Replacement
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 EPG/DVD Top Menu/Info	 D.Menu / Top
 EPG/DVD Top Menu/Info	 Guide / EPG / -/-
 0	 0
 TV/DTV/SAT	 AV / Input / RDS
 P+	 CH+ / Page+
 CH return	 Fav / Marker / PC
 Vol+	 Vol+
 P-	 CH- / Page-
 Mute	 Mute / Dimmer
 Vol-	 Vol-
 Exit	 Exit / Cancel / Clear







































Original	Replacement
	Up
	Setup / OPT /
	Left
	OK
	Right
	Menu / Home
	Down
	Back / Return
	Red / Netflix / Search
	Rec / Rec Mode
	Green / APP / Repeat
	Pause / Step / Freeze
	Yellow / YouTube / Repeat
	Stop / Hold
	Blue / Prime Video / Random
	Play / Slow
	I<< / Preset-

Original	Replacement
	Subtitle / EQ
>> button"/>	>> / Preset+
	Shift + Display / Media
<< button"/>	<< / Tune-
	Shift + Smart / List
>> button"/>	>> / Tune+
	Text / Goto
	Audio / Lang I/II
	Smart / List
	Display / Media





























































Original	Replacement
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 EPG/DVD Top Menu/Guide	 Guide / EPG / -/-
 EPG/DVD Top Menu/Guide	 D.Menu / Top
 0	 0
 Vol+ Tv	 Vol+
 Mute Tv	 Mute / Dimmer
 Vol- Tv	 Vol-
 Up	 Up

Original	Replacement
 Left	 Left
 Enter	 OK
 Right	 Right
 Menu/Home	 Menu / Home
 Down	 Down
 Return	 Back / Return
 Pause	 Pause / Step / Freeze
 Stop	 Stop / Hold
 Play	 Play / Slow
 I<<	 I<< / Preset-
 >>I	 >>I / Preset+
 <<	 << / Tune-
 >>	 >> / Tune+





Original		Replacement		Original		Replacement	
	Power		Power		P-		CH- / Page-
	[i+]/Timer/Info		Info / Angle		Mute Tv		Mute / Dimmer
	[i+]/Timer/Info		Sleep / Timer		Vol- Tv		Vol-
	1		1		X/Exit		Exit / Cancel / Clear
	2		2		Up		Up
	3		3		Left		Left
	4		4		OK		OK
	5		5		Right		Right
	6		6		Menu/Home		Menu / Home
	7		7		Down		Down
	8		8		Return		Back / Return
	9		9				
	EPG/DVD Top Menu/Guide		Guide / EPG / -/-				
	EPG/DVD Top Menu/Guide		D.Menu / Top				
	0		0				
	P+		CH+ / Page+				
	Vol+ Tv		Vol+				





Original	Replacement	Original	Replacement
Power	Power	Pause	Pause / Step / Freeze
1	1	Stop	Stop / Hold
2	2	Play	Play / Slow
3	3	I<<	I<< / Preset-
4	4	>>I	>>I / Preset+
5	5		
6	6		
7	7		
8	8		
9	9		
0	0		
P+	CH+ / Page+		
Vol+ Tv	Vol+		
P-	CH- / Page-		
Mute Tv	Mute / Dimmer		
Vol- Tv	Vol-		
Rec	Rec / Rec Mode		

