


















Original	Replacement	Original	Replacement
 Power Tv	 Power	 ←	 Shift + Left
 NET	 Media	 →	 Shift + Right
 [i+]	 Info	 Pause	 Pause
 FAV	 Shift + Pre Ch	 1	 1
 ATV	 Smart	 2	 2
 DTV	 D. Menu	 3	 3
 SAT	 Shift + Media	 4	 4
 Radio	 TV/R	 5	 5
 Power Source	 Shift + Power	 6	 6
 << Source	 Shift + <<	 7	 7
 Play Source	 Play	 8	 8
 >> Source	 Shift + >>	 9	 9
 USB Rec	 Shift + Rec	 0	 0
 Rec Source	 Rec	 Recall	 Pre Ch
 Rec Stop	 Shift + Stop	 Source	 AV
 Stop Source	 Stop	 I/II/I+II/▼/O	 Dual
 Ready/Time Shift	 Options	 [<>]	 Format





Original	Replacement	Original	Replacement
AV Mode	Shift + AV	OK	Ok
Eco	Shift + 3D	>>	>>
Vol+	Vol +	<<	<<
Vol-	Vol -	>>	>>
Mute	Mute	<<	<<
P+	Ch +	[...]	Subt
P-	Ch -	[≡?]	List
[≡]	Text	[≡o]	Sleep
3D	3D	[≡+]	Eject
End	Exit	Red	Red
EPG	Guide	Green	Green
Back	Back	Yellow	Yellow
Menu	Menu	Blue	Blue
Up	Up		
Down	Down		
Right	Right		
Left	Left		

