





































Original	Replacement
 Mute	 Mute / Dimmer
 Power	 Power
 AV / S / SCART	 AV / Input / RDS
 HDTV / PC / HDMI	 Shift + Fav / Marker / PC
 TV / DTV	 TV/Radio /
 Index / Select	 OK
 Guide / Sub Page	 Shift + Guide / EPG / -/-
 Teletext / Exit	 Exit / Cancel / Clear
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 Up	 Up
 Left	 Left
 Menu	 Menu / Home
 Right	 Right
 Down	 Down

Original	Replacement
 1	 1
 2	 2
 3	 3
 CH+	 CH+ / Page+
 4	 4
 5	 5
 6	 6
 CH-	 CH- / Page-
 7	 7
 8	 8
 9	 9
 Vol+	 Vol+
 -/-	 Guide / EPG / -/-
 0	 0
 Return	 Back / Return
 Vol-	 Vol-
 Surround	 Eject / Surround





Original	Replacement
Wide	Picture / Format
Sound	Sound / Title
Display	Display / Media
Subtitle	Subtitle / EQ
Video Mode	Setup / OPT /
Text	Text / Goto
Info	Info / Angle
Audio Mode	Audio / Lang I/II
Favorites	Fav / Marker / PC
List	Smart / List
Hold	Stop / Hold

Original	Replacement

