



















































































































Original	Replacement	Original	Replacement
 Power	 Power	 8	 8
 Open/Close	 Eject	 9	 9
 Mode/HDMI	 Shift + AV	 0	 0
 Reso/Resolution	 Shift + TV/R	 +10	 Guide
 Home	 Smart	 Call	 Pre Ch
 Pure/Pure Direct	 Shift + Subt	 Input Up	 Ch +
 Mode/Sound	 Sleep	 Input Down	 Ch -
 P/D/Prog Direct	 Shift + Options	 Power Amp	 Shift + Power
 ADJ./Pict.	 Shift + Format	 Mute	 Mute
 CLR/Clear	 Exit	 Vol+	 Vol +
 1	 1	 Vol-	 Vol -
 2	 2	 Top Menu	 Menu
 3	 3	 Pop Up Menu	 Media
 4	 4	 Up	 Up
 5	 5	 Left	 Left
 6	 6	 Enter	 Ok
 7	 7	 Right	 Right









































































Original	Replacement	Original	Replacement
	Down		Down
	Setup		Options
	Return		Back
	S/Search		AV
	Stop		Stop
	Pause		Pause
	Play		Play
	I<<		I<<
	>>I		>>I
	<<		<<
	>>		>>
	Camera/Angle		List
	[...]/Subtitle		Subt
	O)))/Audio		Dual
	Page		TV/R
	Mode		D. Menu
	Repeat All		Text
	Repeat A-B		Shift + Text
	Random		Format
	Disp/Display		Info
	Dimm./Dimmer		3D
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue


















































Original	Replacement	Original	Replacement
 Power	 Power	 8	 8
 Open/Close	 Eject	 9	 9
 Mode/HDMI	 Shift + AV	 0	 0
 Reso/Resolution	 Shift + TV/R	 +10	 Guide
 Home	 Smart	 Call	 Pre Ch
 Pure/Pure Direct	 Shift + Subt	 Input Up	 Ch +
 Mode/Sound	 Sleep	 Input Down	 Ch -
 P/D/Prog Direct	 Shift + Options	 Power Amp	 Shift + Power
 ADJ./Pict.	 Shift + Format	 Mute	 Mute
 CLR/Clear	 Exit	 Vol+	 Vol +
 1	 1	 Vol-	 Vol -
 2	 2	 Top Menu	 Menu
 3	 3	 Pop-Up Menu	 Media
 4	 4	 Up	 Up
 5	 5	 Left	 Left
 6	 6	 Enter	 Ok
 7	 7	 Right	 Right





Original	Replacement	Original	Replacement
	Down		Down
	Setup		Options
	Return		Back
	S/Search		AV
	Stop		Stop
	Pause		Pause
	Play		Play
	I<<		I<<
	>>I		>>I
	<<		<<
	>>		>>
	Camera/Angle		List
	[...]/Subtitle		Subt
	O)))/Audio		Dual
	Page		TV/R
	Mode		D. Menu
	Repeat All		Text
	Repeat A-B		Shift + Text
	Random		Format
	Disp/Display		Info
	Dimm./Dimmer		3D
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue

