







































































Original	Replacement	Original	Replacement
 Power	 Power	 Up	 Up
 [≡i]/Info	 Info	 Down	 Down
 Mute	 Mute	 Right	 Right
 1	 1	 Left	 Left
 2	 2	 Enter	 Ok
 3	 3	 Index	 Media
 4	 4	 List	 List
 5	 5	 CH+	 Ch +
 6	 6	 CH-	 Ch -
 7	 7	 Vol+	 Vol +
 8	 8	 Vol-	 Vol -
 9	 9	 ♥	 Pre Ch
 0	 0	 Sleep	 Sleep
 [≡?]/Source	 AV	 EPG	 Guide
 (O/I/II/Audio	 Dual	 Recall	 Back
 Menu	 Menu	 Red	 Red
 Exit	 Exit	 <<	 <<





Original	Replacement	Original	Replacement
Green	B Green		
Yellow	C Yellow		
Left<<	Left<<		
>>	>>		
Blue	D Blue		
[≡]	Text		
Play	Play		
Pause	Pause		
Stop/Still	Stop		
[≡+]	Format		
Radio	TV/R		
[≡◆]/[+]	3D		
[≡x]	Options		
[≡O]/Subtitle	Subt		
DMP	Smart		
Rec	Rec		

