





































































































Original	Replacement	Original	Replacement
 Power	 Power	 Subtitle	 Subt
 Open/Close	 Eject	 Angle	 Red
 1	 1	 Sur	 Options
 2	 2	 Search Mode	 AV
 3	 3	 Repeat	 Shift + Text
 4	 4	 A-B	 Shift + Play
 5	 5	 Shuffle	 Yellow
 6	 6	 SA-CD	 Smart
 7	 7	 Album+	 Ch +
 8	 8	 Album-	 Ch -
 9	 9	 Zoom	 Shift + Eject
 0	 0	 Picture Navi	 TV/R
 Clear	 Exit	 >>	 >>
 Enter	 Pre Ch	 <<	 <<
 Time/Text	 Text	 Scan >>/Slow	 >>
 Picture Mode	 Format	 << Scan/<	 <<
 Audio	 Dual	 <-/Instant Replay/< Step	 Shift + <<


































	Original	Replacement		Original	Replacement
	Step II>/Instant Advance/·→	 +  Shift + >>I			
	Play	 Play			
	Pause	 Pause			
	Up	 Up			
	Down	 Down			
	Right	 Right			
	Left	 Left			
	Enter	 Ok			
	Display	 Info			
	Menu	 Menu			
	Top Menu	 +  Shift + Menu			
	Return	 Back			
	Stop	 Stop			
	SA-CD/CD	 Media			





	Original	Replacement	Original	Replacement
	Power			
	1			
	2			
	3			
	4			
	5			
	6			
	7			
	8			
	9			
	0			
	Enter			
	Tv/Video			
	Vol+			
	Vol-	