






































































Original	Replacement
 Power On	 Power
 Power Off	 +  Shift + Power
 Zone Device On	 Smart
 Zone Device Off	 +  Shift + Smart
 Net/USB	 +  Shift + 1
 iPod/Play	 +  Shift + 2
 DVD	 +  Shift + 3
 BD	 +  Shift + 4
 Tuner	 +  Shift + 5
 Dock	 +  Shift + 6
 SAT TU	 +  Shift + 7
 SAT/CBL	 +  Shift + 8
 Game	 +  Shift + 9
 V.AUX	 +  Shift + Guide
 Phono	 +  Shift + 0
 CD	 +  Shift + Pre Ch
 DVR	 +  Shift + Info

Original	Replacement
 TV	 TV/R
 Monitor Select	 Blue
 Quick Select 1/BD	 Red
 Quick Select 2/(SAT/CBL)	 Green
 Quick Select	 Yellow
 CH+	 Ch +
 CH-	 Ch -
 Source Select	 AV
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 CH Level/Top	 Info
 Menu	 Menu
 Search/Setup	 Media
 Up	 Up
 Return	 Back
 Down	 Down






Original	Replacement	Original	Replacement
	Right		Right
	Left		Left
	Enter		Ok
	Play		Play
	>>/Mode		>>
	<</Band		<<
	>>I/Tuning▲		>>I
	Stop		Stop
	Pause		Pause
	I<</Tuning▼		I<<
	Multeq		Options
	DYN EQ/VOL		Dual
	A-DSX		Subt
	Restorer		Exit
	Standard		Text
	D/ST		Format
	Simulation		3D
	Pure		Pre Ch
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	+10		Guide
	Shift		List
	Link Menu/Power		Eject
	TV Input		D. Menu
	Sleep		Sleep
	Memory/Party		Rec




















Original	Replacement
 Power On	 Power
 Power Off	 Shift + Power
 Zone Device On	 Smart
 Zone Device Off	 Shift + Smart
 Net/USB	 Shift + 1
 iPod/Play	 Shift + 2
 DVD	 Shift + 3
 BD	 Shift + 4
 Tuner	 Shift + 5
 Dock	 Shift + 6
 SAT TU	 Shift + 7
 SAT/CBL	 Shift + 8
 Game	 Shift + 9
 V.AUX	 Shift + Guide
 Phono	 Shift + 0
 CD	 Shift + Pre Ch
 DVR	 Shift + Info

Original	Replacement
 TV	 TV/R
 Quick Select 1/BD	 Red
 Quick Select 2/(SAT/CBL)	 Green
 Quick Select 3	 Yellow
 CH+	 Ch +
 CH-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Menu	 Menu
 CH Level/Top	 Info
 Return	 Back
 Search/Setup	 AV
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left









Original		Replacement		Original		Replacement	
	Enter		Ok		0		0
	<</Band		<<		+10		Guide
	Play		Play		Shift		3D
	>>/Mode		>>		Link Menu/Power		Media
	>> /Tuning/▲		>>		TV Input		Shift + AV
	Stop		Stop		Sleep		Sleep
	Pause		Pause		Memory/Party		Rec
	<</Tuning▼		<<				
	1		1				
	2		2				
	3		3				
	4		4				
	5		5				
	6		6				
	7		7				
	8		8				
	9		9				
































Original	Replacement
 Power On	 Power
 Power Off	 +  Shift + Power
 Zone Device On	 Smart
 Zone Device Off	 +  Shift + Smart
 NET/USB	 +  Shift + 1
 iPod/Play	 +  Shift + 2
 DVD	 +  Shift + 3
 BD	 +  Shift + 4
 Tuner	 +  Shift + 5
 Dock	 +  Shift + 6
 SAT TU	 +  Shift + 7
 SAT/CBL	 +  Shift + 8
 Game	 +  Shift + 9
 V.AUX	 +  Shift + Guide
 Phono	 +  Shift + 0
 CD	 +  Shift + Pre Ch
 DVR	 +  Shift + Info

Original	Replacement
 TV	 TV/R
 Quick Select 1/BD	 Red
 Quick Select 2/(SAT/CBL)	 Green
 Quick Select	 Yellow
 CH+	 Ch +
 CH-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 CH.Level/Top	 Info
 Menu	 Menu
 Search/Setup	 AV
 Return	 Back
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left





Original		Replacement		Original		Replacement	
	Enter		Ok		9		9
	<</Band		<<		+10		Guide
	Play		Play		Shift		3D
	>>/Mode		>>		Link Menu/Power		Media
	>> /Tuning▲		>>		Tv Input		D. Menu
	Stop		Stop		Sleep		Sleep
	Pause		Pause		Memory/Party		Rec
	<</Tuning▼		<<				
	1		1				
	2		2				
	3		3				
	4		4				
	5		5				
	6		6				
	7		7				
	8		8				
	0		0				

