




















































































Original	Replacement	Original	Replacement
Audio+	 +  Shift + Vol+	Yellow	 Yellow / YouTube / Repeat
Reveal	 Setup / OPT /	Blue	 Blue / Prime Video / Random
Update	 Smart / List	Audio-	 +  Shift + Vol-
Bright- Sys	 +  Shift + CH- /	3	 3
Bright+ Mode	 +  Shift + CH+ /	Tone-	 << / Tune-
AV 2	 +  Shift + AV / Input / RDS	Tone+	 >> / Tune+
4	 4	Color+ P.Std	 Picture / Format
5	 5	Contrast+	 >> / Preset+
6	 6	Color- S.Std	 Sound / Title
7	 7	Contrast-	 I<< / Preset-
8	 8	Surround	 Eject / Surround
9	 9	Nicam/Mono	 +  Shift + Audio / Lang I/II
Guide -/-- 1.	 Guide / EPG / -/--	Level L	 +  Shift + Left
0/10	 0	Level R/Woofer	 +  Shift + Right
2.Fav P/C 2.	 Fav / Marker / PC	Display	 Display / Media
Red	 Red / Netflix / Search	Mute	 Mute / Dimmer
Green	 Green / APP / Repeat	Txt Stop	 Stop / Hold

Original	Replacement	Original	Replacement
Audio+	 +  Shift + Vol+	Yellow	 Yellow / YouTube / Repeat
Reveal	 Setup / OPT /	Blue	 Blue / Prime Video / Random
Update	 Smart / List	Audio-	 +  Shift + Vol-
Bright- Sys	 +  Shift + CH- /	3	 3
Bright+ Mode	 +  Shift + CH+ /	Tone-	 << / Tune-
AV 2	 +  Shift + AV / Input / RDS	Tone+	 >> / Tune+
4	 4	Color+ P.Std	 Picture / Format
5	 5	Contrast+	 >> / Preset+
6	 6	Color- S.Std	 Sound / Title
7	 7	Contrast-	 I<< / Preset-
8	 8	Surround	 Eject / Surround
9	 9	Nicam/Mono	 +  Shift + Audio / Lang I/II
Guide -/-- 1.	 Guide / EPG / -/--	Level L	 +  Shift + Left
0/10	 0	Level R/Woofer	 +  Shift + Right
2.Fav P/C 2.	 Fav / Marker / PC	Display	 Display / Media
Red	 Red / Netflix / Search	Mute	 Mute / Dimmer
Green	 Green / APP / Repeat	Txt Stop	 Stop / Hold



