
































































Original	Replacement	Original	Replacement
 Power	 Power	 Up	 Up
 i	 ANGLE INFO	 RETURN	 RETURN BACK
 INPUT SELECT	 RDS AV INPUT		
 PICTURE SIZE	 FORMAT PICTURE	 ENTER/ CH LIST	 OK
 1	 TV 1	 ENTER/ CH LIST	 LIST SMART
 2	 DVD 2		
 3	 CD - STB 3		 DIMMER MUTE
 4	 VIDEO 4		
 5	 TAPE 5		 EQ SUBTITLE
 6	 TUNER 6		 VOL +
 7	 AUX - HDD 7		 STEP - FREEZE
 8	 USB 8		 CH PAGE +
 9	 BLUETOOTH 9		 VOL -
 AUDIO I / II	 LANG I / II AUDIO		 PC FAV MARKER
 0	 HDMI - BAT 0		 CH PAGE -
 GUIDE EPG	 GUIDE EPG		 GOTO TEXT
 MENU	 HOME MENU		 MEDIA DISPLAY





Original	Replacement	Original	Replacement
	Size		Zoom / Size
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random

Original	Replacement

