
















































Original	Replacement
 Power	 Power
 Source	 AV
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 PR+	 Ch +
 PR-	 Ch -
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0

Original	Replacement
 TV	 TV/R
 Recall	 Pre Ch
 World	 Media
 Menu	 Menu
 Exit	 Exit
 Back	 Back
 i/Info	 Info
 Guide	 Guide
 [≡]/Text	 Text
 */O	 Format
 */O..	 3D
 Lang	 Dual
 [≡]..	 Subt
 [-O-]	 Options
 Red	 Red
 Green	 Green
 Yellow	 Yellow





	Original	Replacement	Original	Replacement
	Blue	 D		
	Rec	 REC MODE		
	Play	 PLAY MODE		
	Stop			
	Pause			
	<<			
	>>			
	OK			
	Up			
	Down			
	Right			
	Left			
	Music/Photo/Movi	 HOME SMART		
	Q.Menu	 E-MANUAL D.MENU		

