Original		Replacement	
	Power		Power
FAV	FAV	FAV PRE-CH	Pre Ch
TV/R	TV/R	SEARCH TV/R	TV/R
1 .,;@	1	1	1
2 ABC	2	2	2
3 DEF	3	3	3
4 GHI	4	4	4
5 JKL	5	5	5
6 MNO	6	6	6
7 PQRS	7	7	7
8 TUV	8	8	8
9 WXYZ	9	9	9
0	0	0	0
PG+	PG+	SHIFT + CH +	Shift + Ch +
PG-	PG-	SHIFT + CH -	Shift + Ch -
BACK	Back	RETURN BACK	Back
	i	DISPLAY INFO	Info

Original		Replacement	
MENU	Menu	TOP MENU MENU	Menu
EXIT/SORTIE	Exit/Sortie	CLEAR EXIT	Exit
GUIDE	Guide	-/-- GUIDE	Guide
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
+ V -	Vol +	+ VOL	Vol +
V -	Vol -	VOL -	Vol -
	Mute	MUTE	Mute
+ P	P+	+ CH	Ch +
P -	P-	CH -	Ch -
SUB	SUB	AD SUBT	Subt
TXT	TXT	REPEAT TEXT	Text
AUDIO	Audio	SOUND DUAL	Dual
LIST	List	DISC NAV LIST	List

Original		Replacement		Original	Replacement
OPT	OPT	SETTINGS OPT	Options		
⊞	[+]	ECO 3D	3D		
⏮	⏮	⏮	⏮		
⏪	<<	⏪	<<		
⏩	>>	⏩	>>		
⏭	⏭	⏭	⏭		
⏺	Rec	REC MODE ⏺	Rec		
▶	Play	PLAY MODE ▶	Play		
⏸	Pause	⏸	Pause		
⏹	Stop	⏹	Stop		
	Red	A	Red		
	Green	B	Green		
	Yellow	C	Yellow		
	Blue	D	Blue		

Original		Replacement	
	Power		Power
FAV	FAV	FAV PRE-CH	Pre Ch
TV/R	TV/R	SEARCH TV/R	TV/R
1 .,;@	1	1	1
2 ABC	2	2	2
3 DEF	3	3	3
4 GHI	4	4	4
5 JKL	5	5	5
6 MNO	6	6	6
7 PQRS	7	7	7
8 TUV	8	8	8
9 WXYZ	9	9	9
0	0	0	0
PG+	PG+	SHIFT + CH +	Shift + Ch +
PG-	PG-	SHIFT + CH -	Shift + Ch -
BACK	Back	RETURN BACK	Back
	i	DISPLAY INFO	Info

Original		Replacement	
MENU	Menu	TOP MENU MENU	Menu
EXIT/SORTIE	Exit/Sortie	CLEAR EXIT	Exit
GUIDE	Guide	-/-- GUIDE	Guide
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
+ V	Vol +	+ VOL	Vol +
V -	Vol -	VOL -	Vol -
	Mute	MUTE	Mute
+ P	P+	+ CH	Ch +
P -	P-	CH -	Ch -
SUB	SUB	AD SUBT	Subt
TXT	TXT	REPEAT TEXT	Text
AUDIO	Audio	SOUND DUAL	Dual
LIST	List	DISC NAV LIST	List

Original		Replacement		Original	Replacement
OPT	OPT	SETTINGS OPT	Options		
⊞	[+]	ECO 3D	3D		
⏮	⊲	⏮	I <<		
⏪	<<	⏪	<<		
⏩	>>	⏩	>>		
⏭	I >	⏭	>>I		
●	Rec	REC MODE ●	Rec		
▶	Play	PLAY MODE ▶	Play		
⏸	Pause	⏸	Pause		
■	Stop	■	Stop		
	Red	A	Red		
	Green	B	Green		
	Yellow	C	Yellow		
	Blue	D	Blue		