Original		Replacement	
	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
	Mute	DIMMER MUTE	Mute / Dimmer
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
RECALL	Recall	RETURN BACK	Back / Return
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
MENU	Menu	HOME MENU	Menu / Home
CH+	Up/CH+		Up
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
VOL-	Left		Left

Original		Replacement	
VOL-	Vol -	VOL	Vol -
OK	OK	OK	OK
VOL+	Right		Right
VOL+	Vol +	VOL	Vol +
Pg Up	Pg Up	CH PAGE	CH+ / Page+
CH-	Down/CH-		Down
Pg Dn	Pg Dn	CH PAGE	CH- / Page-
TV/RADIO	TV/Radio	PROGRAM TV/RADIO	TV/Radio /
INFO	Info	ANGLE INFO	Info / Angle
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
SUB-T	Sub-T	EQ SUBTITLE	Subtitle / EQ
TTX	TTX	GOTO TEXT	Text / Goto
TIMER	Timer	-/-- GUIDE EPG	Guide / EPG / -/--
LIST	List	LIST SMART	Smart / List
II	Pause	STEP - FREEZE II	Pause / Step / Freeze
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer

Original		Replacement	Original	Replacement
RATIO	Ratio	FORMAT PICTURE	Picture / Format	
	Red	NETFLIX SEARCH	Red / Netflix / Search	
	Green	APP REPEAT	Green / APP / Repeat	
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat	
	Blue	Prime Video RANDOM	Blue / Prime Video / Random	