Original		Replacement	
ECO	Eco	TOP MENU D.MENU	D. Menu / Top
	Power		Power
SURROUND	Surround	SURROUND	Eject / Surround
STEREO	Stereo	LANG I/II AUDIO	Audio / Lang I/II
TARGET	Target	HOME MENU	Menu / Home
BEAM	Beam	LIST SMART	Smart / List
HDMI 1	HDMI 1	TV 1	1
HDMI 2	HDMI 2	DVD 2	2
HDMI 3	HDMI 3	CD - STB 3	3
TV	TV	VIDEO 4	4
OPTICAL	Optical	TAPE 5	5
	Bluetooth	BLUETOOTH 9	9
AUX 1	AUX 1	AUX - HDD 7	7
AUX 2	AUX2	USB 8	8
CLEAR VOICE	Clear Voice	CLEAR EXIT CANCEL	Exit / Cancel / Clear
1	System Memory	-/-- GUIDE EPG	Guide / EPG / -/--
2	System Memory	HDMI - SAT 0	0

Original		Replacement	
3	System Memory	PC FAV MARKER	Fav / Marker / PC
SUB +	Sub+	CH PAGE +	CH+ / Page+
CH LEVEL	CH Level	MEDIA DISPLAY	Display / Media
VOL +	Vol +	VOL +	Vol +
SUB -	Sub-	CH PAGE -	CH- / Page-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
VOL -	Vol -	VOL -	Vol -
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Up		Up
OPTION	Option	SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
RETURN	Return	RETURN BACK	Back / Return
	Down		Down
INFO	Info	ANGLE INFO	Info / Angle
MOVIE	Movie	NETFLIX SEARCH	Red / Netflix / Search

Original		Replacement		Original	Replacement
MUSIC	Music	APP REPEAT	Green / APP / Repeat		
ENTER TAINMENT	Entertainment	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
OFF	Off	Prime Video RANDOM	Blue / Prime Video / Random		
ENHANCER	Enhancer	GOTO TEXT	Text / Goto		
UNI VOLUME	Uni volume	RDS AV INPUT	AV / Input / RDS		
BLUETOOTH STANDBY	Bluetooth	FORMAT PICTURE	Picture / Format		
SUBWOOFER PAIRING	Subwoofer Pairin	SIZE ZOOM	Zoom / Size		
REPEATER	Repeater	SHIFT + APP REPEAT	Shift + Green / APP /		