Original		Replacement	
POWER	Power		Power
MENU PBC	Menu PBC	HOME MENU	Menu / Home
TITLE	Title	TITLE SOUND	Sound / Title
	Open / Close	RDS AV INPUT	AV / Input / RDS
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
10/0	10/0	HDMI - SAT 0	0
10+	10+	-/-- GUIDE EPG	Guide / EPG / -/--
	Clear	PC FAV MARKER	Fav / Marker / PC
	Display	MEDIA DISPLAY	Display / Media

Original		Replacement	
	Subtitle	EQ SUBTITLE	Subtitle / EQ
	Slow	STEP - FREEZE II	Pause / Step / Freeze
	Program	PROGRAM TV/ RADIO	TV/Radio /
	USB	FORMAT PICTURE	Picture / Format
	Audio	LANG I/II AUDIO	Audio / Lang I/II
	Mute	DIMMER MUTE	Mute / Dimmer
	Repeat	APP REPEAT	Green / APP / Repeat
	Setup	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Up		Up
	Zoom	GOTO TEXT	Text / Goto
	Play / Pause	SLOW	Play / Slow
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
	Stop	HOLD	Stop / Hold
	SRC	RETURN BACK	Back / Return
	Down		Down

Original		Replacement	
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	Vol-	VOL −	Vol-
	Vol+	+ VOL	Vol+
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+

Original	Replacement