Original		Replacement	
	Power		Power
1	1	1	1
ABC 2	2	2	2
DEF 3	3	3	3
GHI 4	4	4	4
JKL 5	5	5	5
MNO 6	6	6	6
PQRS 7	7	7	7
TUV 8	8	8	8
WXYZ 9	9	9	9
0	0	0	0
Audio PIP	PIP/Audio	ECO 3D	3D
	[<>]	PICTURE FORMAT	Format
?	?	HOME SMART	Smart
	Mute	MUTE	Mute
Disc Menu Z	Z/Disc Menu	TOP MENU MENU	Menu
OSD i	i/OSD	DISPLAY INFO	Info

Original		Replacement	
TXT	TXT	REPEAT TEXT	Text
TV-G	TV-G	GUIDE	Guide
P+	Up		Up
P-	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
P+	P+	CH +	Ch +
P-	P-	CH −	Ch -
	Vol+	VOL +	Vol +
	Vol-	VOL −	Vol -
	Red/Image/I>	A	Red
	Green/Timer	B	Green
	Yellow/@	C	Yellow
	Blue/Sound	D	Blue
	Play	PLAY MODE	Play
	Pause		Pause

Original	Replacement	Original	Replacement
Stop	Stop		
<<	<<		
>>	>>		
I<	I<<		
>I	>>I		

Original		Replacement	
	Power		Power
1	1	1	1
ABC 2	2	2	2
DEF 3	3	3	3
GHI 4	4	4	4
JKL 5	5	5	5
MNO 6	6	6	6
PQRS 7	7	7	7
TUV 8	8	8	8
WXYZ 9	9	9	9
0	0	0	0
Audio PIP	PIP/Audio	ECO 3D	3D
	[<>]	PICTURE FORMAT	Format
?	?	HOME SMART	Smart
OSD i	i/OSD	DISPLAY INFO	Info
TXT	TXT	REPEAT TEXT	Text
TV-G	TV-G	-/-- GUIDE	Guide

Original		Replacement	
Disc Menu Z	Z/Disc Menu	TOP MENU MENU	Menu
P+	Up		Up
P-	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
P+	P+	+ CH	Ch +
P-	P-	CH –	Ch -
	Vol+	+ VOL	Vol +
	Vol-	VOL –	Vol -
	Red/Image/I>	A	Red
	Green/Timer	B	Green
	Yellow/@	C	Yellow
	Blue/Sound	D	Blue
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop

Original		Replacement		Original	Replacement
TXT	<<		<<		
TV-G	>>		>>		
	>I		>>I		
?	I<		I<<		

Original		Replacement	
	Power		Power
1	1	1	1
ABC 2	2	2	2
DEF 3	3	3	3
GHI 4	4	4	4
JKL 5	5	5	5
MNO 6	6	6	6
PQRS 7	7	7	7
TUV 8	8	8	8
WXYZ 9	9	9	9
0	0	0	0
Audio PIP	PIP/Audio	ECO 3D	3D
	[<>]	PICTURE FORMAT	Format
?	?	HOME SMART	Smart
	Mute	MUTE	Mute
OSD i	i/OSD	DISPLAY INFO	Info
TXT	TXT	REPEAT TEXT	Text

Original		Replacement	
Disc Menu Z	Z/Disc Menu	TOP MENU MENU	Menu
TV-G	TV-G	GUIDE	Guide
P+	Up		Up
P-	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
P+	P+	+ CH	Ch +
P-	P-	CH −	Ch -
	Vol+	+ VOL	Vol +
	Vol-	VOL −	Vol -
	Red/Image/I>	A	Red
	Green/Timer	B	Green
	Yellow/@	C	Yellow
	Blue/Sound	D	Blue
	Play	PLAY MODE	Play
	Pause		Pause

Original		Replacement		Original	Replacement
	Stop		Stop		
	<<		<<		
	>>		>>		
	I<		I<<		
	>I		>>I		

Original		Replacement	
	Power		Power
1	1	1	1
ABC 2	2	2	2
DEF 3	3	3	3
GHI 4	4	4	4
JKL 5	5	5	5
MNO 6	6	6	6
PQRS 7	7	7	7
TUV 8	8	8	8
WXYZ 9	9	9	9
0	0	0	0
Audio PIP	PIP/Audio	ECO 3D	3D
	[<>]	PICTURE FORMAT	Format
?	?	HOME SMART	Smart
OSD i	i/OSD	DISPLAY INFO	Info
TXT	TXT	REPEAT TEXT	Text
TV-G	TV-G	-/-- GUIDE	Guide

Original		Replacement	
Disc Menu Z	Z/Disc Menu	TOP MENU MENU	Menu
P+	P+	+ CH	Ch +
P-	P-	CH −	Ch -
P+	Up		Up
P-	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
	Vol+	+ VOL	Vol +
	Vol-	VOL −	Vol -
	Red/Image/I>	A	Red
	Green/Timer	B	Green
	Yellow/@	C	Yellow
	Blue/Sound	D	Blue
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop

Original	Replacement	Original	Replacement
<<	<<		
>>	>>		
I<	I<<		
>I	>>I		