Original		Replacement	
	Source	RDS AV INPUT	AV / Input / RDS
	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI - SAT 0	0
PRE PR	Pre PR	RETURN BACK	Back / Return
HDMI	HDMI	SHIFT + HDMI - SAT 0	Shift + 0
YPbPr	YPbPr	TOP MENU D.MENU	D. Menu / Top
VIDEO	Video	SHIFT + VIDEO 4	Shift + 4

Original		Replacement	
PC	PC	PC FAV MARKER	Fav / Marker / PC
	Vol +	VOL +	Vol +
	Mute	DIMMER MUTE	Mute / Dimmer
P	PR+	CH PAGE +	CH+ / Page+
	Vol -	VOL −	Vol -
	[<>]	FORMAT PICTURE	Picture / Format
P	PR-	CH PAGE −	CH- / Page-
DUAL	Dual	LANG I/II AUDIO	Audio / Lang I/II
AUDIO ADJ	Adj Audio	TITLE SOUND	Sound / Title
VIDEO ADJ	Adj Video	SHIFT + FORMAT PICTURE	Shift + Picture / Format
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
MENU /EXIT	Menu/Exit	HOME MENU	Menu / Home
	Down		Down

Original		Replacement		Original		Replacement	
	[i+]	ANGLE INFO	Info / Angle				
	Red	NETFLIX SEARCH	Red / Netflix / Search				
	Green	APP REPEAT	Green / APP / Repeat				
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
	Blue	Prime Video RANDOM	Blue / Prime Video / Random				
TELETEXT	Teletext	GOTO TEXT	Text / Goto				
MIX	Mix	SHIFT +	GOTO TEXT Shift + Text /				
SIZE	Size	SIZE ZOOM	Zoom / Size				
SUBPAGE	Subpage	SURROUND	Eject / Surround				
INDEX	Index	PROGRAM TV/ RADIO	TV/ Radio /				
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ				
HOLD	Hold	HOLD	Stop / Hold				
REVEAL	Reveal	MEDIA DISPLAY	Display / Media				
ECO	Eco	OPT-TOOLS SETUP	Setup / OPT /				
PR LIST	PR List	LIST SMART	Smart / List				
FREEZE	Freeze	STEP-FREEZE	Pause / Step / Freeze				
	Nothing	CLEAR EXIT CANCEL	Exit / Cancel / Clear				