Original		Replacement	
	Input	RDS AV INPUT	AV / Input / RDS
	Power		Power
	[▼]	PC FAV MARKER	Fav / Marker / PC
TEXT	Text	GOTO TEXT	Text / Goto
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
	O)/I/II	LANG I/II AUDIO	Audio / Lang I/II
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
AD	AD	TITLE SOUND	Sound / Title
0	0	HDMI - SAT 0	0

Original		Replacement	
ATV/ DTV	ATV/DTV	PROGRAM TV/ RADIO	TV/Radio /
+	Vol+	+ VOL	Vol+
	[≡i]/[i+]	ANGLE INFO	Info / Angle
P	PR+	+ CH PAGE	CH+ / Page+
−	Vol-	VOL −	Vol-
	Mute	DIMMER MUTE	Mute / Dimmer
P	PR-	CH PAGE −	CH- / Page-
QUICK	Quick	LIST SMART	Smart / List
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
	Up		Up
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Left		Left
OK	OK	OK	OK
	Right		Right
MENU	Menu	HOME MENU	Menu / Home
	Down		Down
RETURN	Return	RETURN BACK	Back / Return

Original	Replacement	Original	Replacement
Red	Red / Netflix / Search		
Green	Green / APP / Repeat		
Yellow	Yellow / YouTube / Repeat		
Blue	Blue / Prime Video / Random		
[≡?]	Display / Media		
[≡+]	Stop / Hold		
[≡♦]	Zoom / Size		
Timer/[≡x]	Sleep / Timer		