Original		Replacement	
BD	Power BD		Power
	Power Tv	SHIFT +	Shift + Power
CH+	CH+ Tv	SHIFT +	Shift + CH+ /
VOL +	Vol + Tv		Vol +
DRIVE SELECT	Drive Select	TOP MENU D.MENU	D. Menu / Top
AV	AV Tv	SHIFT + RDS AV INPUT	Shift + AV / Input / RDS
CH-	CH- Tv	SHIFT + CH PAGE –	Shift + CH- /
VOL -	Vol - Tv	VOL –	Vol -
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
PAGE CH+	CH+	+ CH PAGE	CH+ / Page+
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
CH-	CH-	CH PAGE –	CH- / Page-
7	7	AUX-HDD 7	7

Original		Replacement	
8	8	USB 8	8
9	9	BLUETOOTH 9	9
PROG/CHECK	Prog/Check	PROGRAM TV/RADIO	TV/Radio /
DELETE *	Delete/*	SIZE ZOOM	Zoom / Size
0	0	HDMI-SAT 0	0
INPUT SELECT	Input Select	RDS AV INPUT	AV / Input / RDS
MANUAL SKIP	Manual Skip	FORMAT PICTURE	Picture / Format
	I<< Skip	PRESET-	I<< / Preset-
	Skip >>I	PRESET+	>>I / Preset+
	<< Slow/Search	TUNE-	<< / Tune-
	Slow/Search >>	TUNE+	>> / Tune+
STOP	Stop	HOLD	Stop / Hold
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
PLAY/x1.3	Play/x1.3	SLOW	Play / Slow
STATUS i	i/Status	ANGLE INFO	Info / Angle
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--

Original	Replacement	Original	Replacement
Direct Navigator/Pop-up	Smart / List	Text	Text / Goto
Left/◁II	Left	[≡◆]/Sttl	Subtitle / EQ
OK	OK	Display	Display / Media
Up	Up	Time Slip	Sleep / Timer
Right/II▷	Right		
Function/Menu	Menu / Home		
Option	Setup / OPT /		
Down	Down		
Return	Back / Return		
Red	Red / Netflix / Search		
Green	Green / APP / Repeat		
Yellow/Create Chapter	Yellow / YouTube / Repeat		
Blue	Blue / Prime Video / Random		
Rec	Rec / Rec Mode		
Rec Mode	Shift + Rec / Rec Mode		
Audio	Audio / Lang I/II		
Direct Tv Rec	Eject / Surround		