Original		Replacement	
	Power		Power
AUDIO SOURCE	Source / Audio	TIMER AV	AV
RADIO	Radio	SEARCH TV/R	TV/R
USB	USB	APP MEDIA	Media
AUDIO SYNC	Sync / Audio	AD SUBT	Subt
	Home	HOME SMART	Smart
DISC	Disc	DISC NAV LIST	List
OPEN/CLOSE	Open / Close	FAV PRE-CH	Pre Ch
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
BACK	Back	RETURN BACK	Back
OPTIONS	Options	SETTINGS OPT	Options
	Vol +	+ VOL	Vol +
	Vol -	VOL −	Vol -

Original		Replacement	
	Mute	MUTE	Mute
	>>		>>
	<<		<<
	Stop		Stop
	I<		I<<
	>I		>>I
	Play	PLAY MODE	Play
	Pause		Pause
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9

Original		Replacement	
0	0	0	0
SOUND	Sound	SOUND DUAL	Dual
SURR	Surr	PICTURE FORMAT	Format

Original	Replacement