Original		Replacement	
	Digital		Display / Media
	Yellow/Theater Modes/Info		Yellow / YouTube / Repeat
	Power		Power
	Tv		Shift + 1
	DVD		Shift + 2
	Green/Stereo/[..		Green / APP / Repeat
	Blue/Delay/Titl		Blue / Prime Video / Random
	Red/Center/Audio		Red / Netflix / Search
	Up		Up
	Violet/Level/Cam		Fav / Marker / PC
	Tape		Shift + 5
	SAT/CAB		Shift + 0
	Tuner		Shift + 6
	Video/VCR		Shift + 4
	Left/-		Left
	OK		OK
	Right/+		Right

Original		Replacement	
	PTY		Text / Goto
	Down		Down
	Menu/RDS		Menu / Home
	Vol +		Vol +
	PR+/>>I		CH+ / Page+
	Vol -		Vol -
	PR-/I<<		CH- / Page-
	Mute		Mute / Dimmer
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9

Original	Replacement	Original	Replacement
Memo / Clear	Smart / List		
0	0		

Original		Replacement	
	Digital		Display / Media
	Yellow/Theater Modes/Info		Yellow / YouTube / Repeat
	Power		Power
	TV		Shift + 1
	DVD		Shift + 2
	Green/Stereo/[..		Green / APP / Repeat
	Blue/Delay/Titl		Blue / Prime Video / Random
	Red/Center/Audio		Red / Netflix / Search
	Up		Up
	Violet/Level/Cam		Fav / Marker / PC
	Tape		Shift + 5
	SAT/CAB		Shift + 0
	Tuner		Shift + 6
	Video/VCR		Shift + 4
	Left/-		Left
	OK		OK
	Right/+		Right

Original		Replacement	
	Down		Down
	Menu/RDS		Menu / Home
	Vol +		Vol +
	PR+/>>I		>>I / Preset+
	PR+/>>I		CH+ / Page+
	Vol -		Vol -
	PR-/I<<		I<< / Preset-
	PR-/I<<		CH- / Page-
	Mute		Mute / Dimmer
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8

Original	Replacement	Original	Replacement
9	9		
Memo/ Clear	Smart / List		
0	0		
<<	<< / Tune-		
Play	Play / Slow		
>>	>> / Tune+		
Rec	Rec / Rec Mode		
Stop	Stop / Hold		
Pause	Pause / Step / Freeze		

Original	Replacement	Original	Replacement
Digital	Display / Media	PTY	Text / Goto
Yellow/Theater Modes/Info	Yellow / YouTube / Repeat	Down	Down
Power	Power	Menu/RDS	Menu / Home
TV	Shift + 1	Vol +	Vol +
DVD	Shift + 2	PR+/ >>I	CH+ / Page+
Green/Stereo/[. .	Green / APP / Repeat	Vol -	Vol -
Blue/Delay/Titl	Blue / Prime Video / Random	PR- / I <<	CH- / Page-
Red/Center/Audio	Red / Netflix / Search	Mute	Mute / Dimmer
Up	Up	1	1
Violet/Level/Cam	Fav / Marker / PC	2	2
Tape	Shift + 5	3	3
SAT/CAB	Shift + 0	4	4
Tuner	Shift + 6	5	5
Video/VCR	Shift + 4	6	6
Left/-	Left	7	7
OK	OK	8	8
Right/+	Right	9	9

Original	Replacement	Original	Replacement
Memo/ Clear	Smart / List		
0	0		
<<	<< / Tune-		
Play	Play / Slow		
>>	>> / Tune+		
Rec	Rec / Rec Mode		
Stop	Stop / Hold		
Pause	Pause / Step / Freeze		

Original	Replacement	Original	Replacement
Digital	Display / Media	Right / +	Right
Yellow/ Theater Modes/ Info	Yellow / YouTube / Repeat	PTY	Text / Goto
Power	Power	Down	Down
Tv	Shift + 1	Menu/ RDS	Menu / Home
DVD	Shift + 2	Menu/ RDS	AV / Input / RDS
Green/ Stereo/ [. .	Green / APP / Repeat	Vol +	Vol +
Blue/ Delay/ Titl	Blue / Prime Video / Random	PR+/ >>I	CH+ / Page+
Red/ Center/ Audio	Audio / Lang I/II	PR+/ >>I	>>I / Preset +
Red/ Center/ Audio	Red / Netflix / Search	Vol -	Vol -
Up	Up	PR- / I <<	CH- / Page-
Violet/ Camera/ Le	Fav / Marker / PC	PR- / I <<	I << / Preset -
Tape	Shift + 5	Mute	Mute / Dimmer
SAT/ CAB	Shift + 0	1	1
Tuner	Shift + 6	2	2
Video/ VCR	Shift + 4	3	3
Left / -	Left	4	4
OK	OK	5	5

Original	Replacement	Original	Replacement
6	6		
7	7		
8	8		
9	9		
Memo/Clear	Smart / List		
0	0		
<<	<< / Tune-		
Play	Play / Slow		
>>	>> / Tune+		
Rec	Rec / Rec Mode		
Stop	Stop / Hold		
Pause	Pause / Step / Freeze		