Original		Replacement	
POWER	Power		Power
DVD	DVD	A	Red
VCR	VCR	B	Green
EJECT OPEN/CLOSE	Eject/Open/Close	ZOOM	Eject
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
CLEAR	Clear	CLEAR EXIT	Exit
AV/INPUT	Av/Input	TIMER AV	AV
FORWARD	>>/Forward		>>

Original		Replacement	
BACKWARD	<<</Backward		<<
SKIP	>>I Skip		>>I
SKI	I<< Skip		I<<
PAUSE/STEP	Pause/Step		Pause
PLAY	Play	PLAY MODE	Play
STOP	Stop		Stop
HOME	Home	HOME SMART	Smart
DISC MENU/LIST	Disc Menu/List	DISC NAV LIST	List
DISPLAY	Display	DISPLAY INFO	Info
RETURN	Return	RETURN BACK	Back
PR/CH TRK	PR/CH TRK +		Up
	PR/CH TRK - Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
AUDIO	O))/Audio	SOUND DUAL	Dual
SUBTITLE	Subtitle	AD SUBT	Subt

Original		Replacement	
ZOOM	Zoom	SHIFT + ZOOM	Shift + Eject
I.SKIP	I. Skip	REPEAT TEXT	Text
REC	Rec	REC MODE	Rec
REC MODE	Rec Mode	SHIFT + REC MODE	Shift + Rec
DUBBING	Dubbing	-/-- GUIDE	Guide
TITLE	Title	SETTINGS OPT	Options
PLAY MODE	Play Mode	SHIFT + PLAY MODE	Shift + Play
MARKER	Marker	C	Yellow
- SEARCH	- Search	SHIFT + SEARCH TV/R	Shift + TV/R
THUMBNAIL	Thumbnail	APP MEDIA	Media
CHP. ADD	CHP. ADD	PICTURE FORMAT	Format
TV/VCR	Tv/VCR	SEARCH TV/R	TV/R
*	*	D	Blue
SHOWVIEW	Show/View	ECO 3D	3D
TV POWER	Power Tv	SHIFT +	Shift + Power
AV/INPUT	Av/Input Tv	SHIFT + TIMER AV	Shift + AV
PR/CH	PR/CH + Tv	+ CH	Ch +

Original		Replacement	
	PR/CH - Tv	CH –	Ch -
VOL	Vol + Tv	+ VOL	Vol +
	Vol - Tv	VOL –	Vol -