Original		Replacement	
	Power		Power
1	1	1	1
ABC 2	2	2	2
DEF 3	3	3	3
GHI 4	4	4	4
JKL 5	5	5	5
MNO 6	6	6	6
PQRS 7	7	7	7
TUV 8	8	8	8
WXYZ 9	9	9	9
0	0	0	0
Audio PIP	PIP/Audio	ECO 3D	3D
	[<>]	PICTURE FORMAT	Format
?	?	HOME SMART	Smart
	Mute	MUTE	Mute
Disc Menu Z	Z/Disc Menu	TOP MENU MENU	Menu
OSD i	i/OSD	DISPLAY INFO	Info

Original		Replacement	
TXT	TXT	REPEAT TEXT	Text
TV-G	TV-G	GUIDE	Guide
P+	Up		Up
P-	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
P+	P+	CH +	Ch +
P-	P-	CH -	Ch -
	Vol +	VOL +	Vol +
	Vol -	VOL -	Vol -
	Red/Image/I>	A	Red
	Green/Timer	B	Green
@	Yellow/@	C	Yellow
	Blue/Sound	D	Blue
	Play	PLAY MODE	Play
@	Pause		Pause

Original	Replacement	Original	Replacement
Stop	Stop		
<<	<<		
>>	>>		
I <	I <<		
>I	>>I		

Original	Replacement	Original	Replacement
Power	Power	Z/ Di sc Menu	Menu
1	1	Up	Up
2	2	Down	Down
3	3	Ri ght	Ri ght
4	4	Left	Left
5	5	OK	Ok
6	6	P+	Ch +
7	7	P-	Ch -
8	8	Vol +	Vol +
9	9	Vol -	Vol -
0	0	Red/ I mage/ I >	Red
PI P/ Audi o	3D	Gr een/ Ti mer	Gr een
[<>]	For mat	Yel l ow/ @	Yel l ow
?	Smart	Bl ue/ Sound	Bl ue
i / OSD	I nf o	Pl ay	Pl ay
TXT	Text	Pause	Pause
TV- G	Gui de	St op	St op

Original	Replacement	Original	Replacement
TXT <<	<< <<		
TV-G >>	>> >>		
>|	>>|		
? | <	|<< | <<		

Original		Replacement	
	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
Audio PIP	PIP/Audio	ECO 3D	3D
	[<>]	PICTURE FORMAT	Format
?	?	HOME SMART	Smart
	Mute	MUTE	Mute
OSD i	i/OSD	DISPLAY INFO	Info
TXT	TXT	REPEAT TEXT	Text

Original		Replacement	
Disc Menu Z	Z/Disc Menu	TOP MENU MENU	Menu
TV-G	TV-G	GUIDE	Guide
P+	Up		Up
P-	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
P+	P+	CH +	Ch +
P-	P-	CH -	Ch -
	Vol +	VOL +	Vol +
	Vol -	VOL -	Vol -
	Red/Image/I>	A	Red
	Green/Timer	B	Green
@	Yellow/@	C	Yellow
	Blue/Sound	D	Blue
	Play	PLAY MODE	Play
@	Pause		Pause

Original	Replacement	Original	Replacement
Stop	Stop		
<<	<<		
>>	>>		
I <	I <<		
>I	>>I		

Original		Replacement	
	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
Audio PIP	PIP/Audio	ECO 3D	3D
	[<>]	PICTURE FORMAT	Format
?	?	HOME SMART	Smart
OSD i	i/OSD	DISPLAY INFO	Info
TXT	TXT	REPEAT TEXT	Text
TV-G	TV-G	-/-- GUIDE	Guide

Original		Replacement	
Disc Menu Z	Z/Disc Menu	TOP MENU MENU	Menu
P+	P+	+ CH	Ch +
P-	P-	CH -	Ch -
P+	Up		Up
P-	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
	Vol +	+ VOL	Vol +
	Vol -	VOL -	Vol -
	Red/Image/I>	A	Red
	Green/Timer	B	Green
	Yellow/@	C	Yellow
	Blue/Sound	D	Blue
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop

Original	Replacement	Original	Replacement
<<	<<		
>>	>>		
I <	I <<		
>I	>>I		