Original		Replacement	
	Power		Power
	Mute	MUTE	Mute
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
LIST	List	DISC NAV LIST	List
	Previous Channel	RETURN BACK	Back
VOL+	Vol +	+ VOL	Vol +
VOL-	Vol -	VOL −	Vol -
ASPECT	Aspect	PICTURE FORMAT	Format

Original		Replacement	
LANGNICAM	Lang / NI CAM	SOUND DUAL	Dual
INPUT	Input	TIMER AV	AV
CH+	CH +	+ CH	Ch +
CH-	CH -	CH −	Ch -
	Up		Up
	Right		Right
	Down		Down
	Left		Left
ENTER	Enter	OK	Ok
MENU	Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit
DISPLAY	Display	DISPLAY INFO	Info
PMODE	P. Mode	SHIFT + PICTURE FORMAT	Shift + Format
SMODE	S. Mode	SHIFT + SOUND DUAL	Shift + Dual
SLEEP	Sleep	PROG SLEEP	Sleep
FAV	FAV	FAV PRE-CH	Pre Ch
FAV-	FAV -	SHIFT + CH −	Shift + Ch -

Original	Replacement
FAV +	SHIFT + CH + (Shift + Ch +)
EPG	GUIDE (Guide)
Text	TEXT (Text)
Hold	3D (3D)
TV / Radio	TV/R (TV/R)
Subtitle	SUBT (Subt)
Index / <<	<<
Size / >>	>>
Reveal / I <<	I <<
Subpage / >>I	>>I
Rec	REC MODE (Rec)
Play / Pause	PLAY MODE (Play)
Play / Pause	II (Pause)
Stop	■ (Stop)
Media	MEDIA (Media)
Red	A (Red)
Green	B (Green)

Original	Replacement
Yellow	C (Yellow)
Blue	D (Blue)