Original		Replacement	
	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
FAV	FAV	FAV PRE-CH	Pre Ch
TXT	TXT	REPEAT TEXT	Text
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue

Original		Replacement	
GUIDE	Guide	-/-- GUIDE	Guide
?	?	SOUND DUAL	Dual
EXIT	Exit	CLEAR EXIT	Exit
MENU	Menu	TOP MENU MENU	Menu
TOOLS	Tools	SETTINGS OPT	Options
BACK	Back	RETURN BACK	Back
@	@	HOME SMART	Smart
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
+ VOL	Vol +	+ VOL	Vol +
- VOL	Vol -	- VOL	Vol -
	Mute	MUTE	Mute
	Source	TIMER AV	AV
+ P	P+	+ CH	Ch +

Original		Replacement		Original	Replacement
P	P-	CH	Ch -		
I<	I<	I<<	I<<		
>I	>I	>>I	>>I		
<<	<<	<<	<<		
>>	>>	>>	>>		
Rec	Rec	REC MODE	Rec		
Play	Play	PLAY MODE	Play		
Pause	Pause	Pause	Pause		
Stop	Stop	Stop	Stop		
3D	3D	ECO 3D	3D		
OQ	OQ	PICTURE FORMAT	Format		
[...]..	[...]..	AD SUBT	Subt		
NETFLIX	Netflix	SHIFT + APP MEDIA	Shift + Media		
MY MEDIA	My Media	APP MEDIA	Media		