Mandis shop

TW6

| Original | Replacement |
|---|---|
| Power | Power |
| Sleep | Sleep / Timer |
| Mute | Mute / Dimmer |
| iPod Menu | Menu / Home |
| Menu Up | Up |
| Source | AV / Input / RDS |
| I<< | I<< / Preset- |
| Enter | OK |
| >>I | >>I / Preset+ |
| Mem Time | TV/Radio / |
| Menu Down | Down |
| Play / Pause | Play / Slow |
| Treble + | CH+ / Page+ |
| Bass + | Right |
| Volume + | Vol+ |
| Treble - | CH- / Page- |
| Bass - | Left |

| Original | Replacement |
|---|---|
| Volume - | Vol- |

https://all-remotes.online/en/1059499-85021-replacement-remote-control-for-TW6.html