Mandis shop

AVERMEDIA RM-NN

Original	Replacement
Power	Power
Source / Mode (↔)	AV / Input / RDS
Menu	Menu / Home
Up	Up
Info	Info / Angle
Left	Left
OK	OK
Right	Right
Recall	Fav / Marker / PC
Down	Down
Back	Back / Return
Rec	Rec / Rec Mode
Picture	Picture / Format
Play	Play / Slow
Pause	Pause / Step / Freeze
<< REW	<< / Tune-
Stop	Stop / Hold

Original	Replacement
>> FF	>> / Tune+
I< / Page -	I<< / Preset-
I< / Page -	CH- / Page-
I> Slow	Smart / List
>I Page +	CH+ / Page+
>I Page +	>>I / Preset+
Quality	Display / Media
Disk Info	Shift + Info / Angle
Delete	Exit / Cancel / Clear
F1 / Eject	1
F1 / Eject	Eject / Surround
F2	2
F3	3

https://all-remotes.online/en/AVERMEDIA/1059675-81929-replacement-remote-control-for-AVERMEDIA-RM-NN.html