Original	Replacement	Original	Replacement
On/Standby	Power	Up	Up
Display	Display / Media	Left	Left
DVD / BD	Shift + 2	Enter	OK
VCR / DVR	Shift + 4	Right	Right
CBL/SAT	Shift + 0	Setup	Setup / OPT /
Game	Shift + 8	Down	Down
AUX	Shift + 7	Return	Back / Return
TUNER	Shift + 6	Home/Audio	Menu / Home
TV / CD	Shift + 1	Home/Audio	Audio / Lang I/II
TV / CD	Shift + 3	I <<	I << / Preset-
PORT	Shift + 5	>>I	>>I / Preset+
PC	Shift + Fav / Marker / PC	<<	<< / Tune-
Muting	Mute / Dimmer	Play	Play / Slow
CH/Disc/Album	CH+ / Page+	>>	>> / Tune+
Vol +	Vol +	Pause	Pause / Step / Freeze
CH/Disc/Album	CH- / Page-	Stop	Stop / Hold
Vol -	Vol -	Movie Tv	Red / Netflix / Search

Original		Replacement		Original		Replacement	
MUSIC REPEAT	Music	APP REPEAT	Green / APP / Repeat	CLR SLEEP 12	CLR/ Sleep/ 12	CLEAR EXIT CANCEL	Exit / Cancel / Clear
GAME RANDOM	Game	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
THX PLAY MODE	THX	Prime Video RANDOM	Blue / Prime Video / Random				
1	1	TV 1	1				
2	2	DVD 2	2				
3	3	CD - STB 3	3				
4	4	VIDEO 4	4				
5	5	TAPE 5	5				
6	6	TUNER 6	6				
7	7	AUX - HDD 7	7				
8	8	USB 8	8				
9	9	BLUETOOTH 9	9				
+10 D.TUN DIMMER	+10/ - - / - - - 10/ Dimmer / D. Tun	-/-- GUIDE EPG	Guide / EPG / - / - -				
+10 D.TUN DIMMER	+10/ - - / - - - 10/ Dimmer / D. Tun	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer				
0 11	0/ 11	HDMI - SAT 0	0				
CLR SLEEP 12	CLR/ Sleep/ 12	PC FAV MARKER	Fav / Marker / PC				
CLR SLEEP 12	CLR/ Sleep/ 12	TIMER SLEEP	Sleep / Timer				

Original	Replacement
Power	Power
DVD/BD	Shift + 2
VCR / DVR	Shift + 4
CBL/SAT	Shift + 0
Game	Shift + 8
AUX	Shift + 7
TUNER	Shift + 6
TV / CD	Shift + 3
TV / CD	Shift + 1
PORT	Shift + 5
PC	Shift + Fav / Marker / PC
Muting Receiver	Mute / Dimmer
Vol + Receiver	Vol +
Vol - Receiver	Vol -
Top Menu	D. Menu / Top
Up	Up
Menu	Menu / Home

Original	Replacement
Left	Left
Enter	OK
Right	Right
Setup	Setup / OPT /
Down	Down
Return	Back / Return
Audio	Audio / Lang I/II
I <<	I << / Preset-
>>I	>>I / Preset+
<<	<< / Tune-
Play	Play / Slow
>>	>> / Tune+
Pause	Pause / Step / Freeze
Stop	Stop / Hold
Search	Red / Netflix / Search
Repeat	Green / APP / Repeat
Random	Blue / Prime Video / Random

Original		Replacement		Original	Replacement
THX PLAY MODE	Play Mode	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
1	1	TV 1	1		
2	2	DVD 2	2		
3	3	CD - STB 3	3		
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
10 +10 D.TUN DIMMER	+10/--/--10/D.Tu Dimmer	-/-- GUIDE EPG	Guide / EPG / -/--		
11 0	0/11	HDMI - SAT 0	0		
12 CLR SLEEP	CLR/Sleep/12	PC FAV MARKER	Fav / Marker / PC		
12 CLR SLEEP	CLR/Sleep/12	TIMER SLEEP	Sleep / Timer		
12 CLR SLEEP	CLR/Sleep/12	CLEAR EXIT CANCEL	Exit / Cancel / Clear		

Original	Replacement
Power	Power
DVD / BD	Shift + 2
VCR / DVR	Shift + 4
CBL/SAT	Shift + 0
Game	Shift + 8
AUX	Shift + 7
TUNER	Shift + 6
TV/CD	Shift + 3
TV/CD	Shift + 1
PORT	Shift + 5
PC	Shift + Fav / Marker / PC
Muting Receiver	Mute / Dimmer
CH/Disc+	CH+ / Page+
Vol + Receiver	Vol +
CH/Disc-	CH- / Page-
Vol - Receiver	Vol -
Up	Up

Original	Replacement
Left	Left
Enter	OK
Right	Right
Setup	Setup / OPT /
Down	Down
Return	Back / Return
Audio	Audio / Lang I/II
I <<	I << / Preset-
>>I	>>I / Preset+
<<	<< / Tune-
Play	Play / Slow
>>	>> / Tune+
Pause	Pause / Step / Freeze
Stop	Stop / Hold
Search	Red / Netflix / Search
Repeat	Green / APP / Repeat
Random	Blue / Prime Video / Random

Original		Replacement		Original	Replacement
THX PLAY MODE	Play Mode	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
1	1	TV 1	1		
2	2	DVD 2	2		
3	3	CD - STB 3	3		
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
+10 D.TUN DIMMER	+10/ - - / - - 10/ D. Tu Dimmer	GUIDE EPG	Guide / EPG / - / - -		
0	0/ 11	HDMI - SAT 0	0		
CLR SLEEP	CLR/ Sleep/ 12	TIMER SLEEP	Sleep / Timer		
CLR SLEEP	CLR/ Sleep/ 12	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
CLR SLEEP	CLR/ Sleep/ 12	PC FAV MARKER	Fav / Marker / PC		

Original		Replacement	
	Power Receiver		Power
	Muting Receiver		Mute / Dimmer
	CH		CH+ / Page+
	Vol +		Vol +
	CH Disc/Album		CH- / Page-
	Vol -		Vol -
	Up		Up
	Left		Left
	Enter		OK
	Right		Right
	Setup		Setup / OPT /
	Down		Down
	Return		Back / Return
	Audio		Audio / Lang I/II
	I<<		I<< / Preset-
	>>I		>>I / Preset+
	<<		<< / Tune-

Original		Replacement	
	Play		Play / Slow
	>>		>> / Tune+
	Pause		Pause / Step / Freeze
	Stop		Stop / Hold
	Movie TV		Red / Netflix / Search
	Music		Green / APP / Repeat
	Game		Yellow / YouTube / Repeat
	Stereo		Blue / Prime Video / Random
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9

Original	Replacement	Original	Replacement
+10/ - - / - - 10/ D. Tu Dimmer	Guide / EPG / - / - -		
+10/ - - / - - 10/ D. Tu Dimmer	SHIFT + DIMMER MUTE Shift + Mute / Dimmer		
0/ 11	0		
CLR/ Sleep/ 12	Fav / Marker / PC		
CLR/ Sleep/ 12	Exit / Cancel / Clear		
CLR/ Sleep/ 12	Sleep / Timer		