Original		Replacement	
Power	Power	Power	Power
Source	Source	TIMER AV	AV
Picture	Picture	PICTURE FORMAT	Format
Sound	Sound	SHIFT + SOUND DUAL	Shift + Dual
Mute	Mute	MUTE	Mute
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
Menu	Menu	TOP MENU MENU	Menu
Exit	Exit	CLEAR EXIT	Exit

Original		Replacement	
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
CH+	CH+	+ CH	Ch +
CH-	CH-	CH −	Ch -
VOL+	Vol +	+ VOL	Vol +
VOL-	Vol -	VOL −	Vol -
EPG	EPG/Size	GUIDE	Guide
Subtitle	Subtitle/Index	SUBT	Subt
Sleep	Sleep/Hold	PROG SLEEP	Sleep
Text	Text	REPEAT TEXT	Text

Original		Replacement		Original		Replacement	
Code Fav	FAV/ Sub. Code	FAV PRE-CH	Pre Ch				
Reveal TV	Tv/ Reveal	SEARCH TV/R	TV/ R				
Mix Comp	Comp/ Mix	SETTINGS OPT	Options				
Cancel Lang	Lang/ Cancel	SOUND DUAL	Dual				
Info	Info	DISPLAY INFO	Info				
Recall	Recall	RETURN BACK	Back				
I/II	I/II	DISC NAV LIST	List				
Zoom	Zoom	ZOOM ⏏	Eject				
DMP	DMP	HOME SMART	Smart				
▶II	Play	PLAY MODE ▶	Play				
▶II	Pause	II	Pause				
■	Stop	■	Stop				
DMP Display	Display/ DMP	ECO 3D	3D				
◀◀	<<	«	<<				
▶▶	>>	»	>>				
⏮	I <<	⏮	I <<				
⏭	>>I	⏭	>>I				