| Original | | Replacement | |
|---|---|---|---|
| TV DIRECT | TV Direct | LIST SMART | Smart / List |
| DVD | Power DVD | NETFLIX SEARCH | Red / Netflix / Search |
| VCR | Power VCR | APP REPEAT | Green / APP / Repeat |
| Power Audio | | | Power |
| STB | Power STB | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| TV | Power TV | Prime Video RANDOM | Blue / Prime Video / Random |
| DVD | DVD | DVD 2 | 2 |
| VCR | VCR | VIDEO 4 | 4 |
| TV | TV | TV 1 | 1 |
| FM/AM | FM/AM | TUNER 6 | 6 |
| TV/VIDEO | Tv/Video | TAPE 5 | 5 |
| MUTING | Muting | DIMMER MUTE | Mute / Dimmer |
| CHANNEL + | Channel + | CH PAGE + | CH+ / Page+ |
| VOLUME + | Volume+ | VOL + | Vol + |
| — | Channel - | CH PAGE − | CH- / Page- |
| — | Volume- | VOL − | Vol - |
| ON SCREEN DISPLAY | Display/On Screen | MEDIA DISPLAY | Display / Media |

| Original | | Replacement | |
|---|---|---|---|
| DIMMER | Dimmer | SHIFT + DIMMER MUTE | Shift + Mute / Dimmer |
| SLEEP | Sleep | TIMER SLEEP | Sleep / Timer |
| ANALOG/DIGITAL INPUT | Analog/Digital Input | RDS AV INPUT | AV / Input / RDS |
| SMART S SETUP | Smart S Setup | OPT-TOOLS SETUP | Setup / OPT / |
| BASS BOOST | Bass Boost | LANG I/II AUDIO | Audio / Lang I/II |
| TONE | C. Tone | EQ SUBTITLE | Subtitle / EQ |
| A.POSITION | A. Position | TOP MENU D.MENU | D.Menu / Top |
| TEST | Test Tone | GOTO TEXT | Text / Goto |
| EFFECT | Effect | ANGLE INFO | Info / Angle |
| DECODE | Decode | PROGRAM TV/RADIO | TV/Radio / |
| SURROUND | Surround | SURROUND ⏏ | Eject / Surround |
| SUBWFR + | Subwfr+ | ▶ | Right |
| CENTER + | Center+ | ▲ | Up |
| L-SUR + | Surr L+ | SHIFT + VOL + | Shift + Vol + |
| SURR-R + | Surr R+ | SHIFT + CH PAGE + | Shift + CH+ / |
| − | Subwfr- | ◀ | Left |
| − | Center- | ▼ | Down |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Surr L- | SHIFT + VOL − Shift + Vol - | | |
| Surr R- | SHIFT + CH PAGE − Shift + CH+ / | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | Replacement |
|---|---|
| Power Audio | Power |
| Power Tv | SHIFT + Power |
| FM/AM | SURROUND Eject / Surround |
| Tv Vol + | VOL + Vol + |
| Channel + TV | CH + / Page+ |
| Tv Vol - | VOL - Vol - |
| Channel - TV | CH - / Page- |
| Tuning- FM/AM | TUNE- << / Tune- |
| FM Mode FM/AM | LIST SMART Smart / List |
| Tuning+ FM/AM | TUNE+ >> / Tune+ |
| Memory FM/AM | HOME MENU Menu / Home |
| TA/News/Info | ANGLE INFO Info / Angle |
| TA/News/Info | Up |
| PTY- FM/AM | Left |
| PTY+ FM/AM | Right |
| PTY Search | Down |
| PTY Search | NETFLIX SEARCH Red / Netflix / Search |

| Original | Replacement |
|---|---|
| ON SCREEN DISPLAY Display FM/AM | MEDIA DISPLAY Display / Media |
| 1 FM/AM | SHIFT + TV 1 Shift + 1 |
| 1 TV | TV 1 1 |
| BASS 2 FM/AM | SHIFT + DVD 2 Shift + 2 |
| BASS 2 TV | DVD 2 2 |
| TREBLE 3 FM/AM | SHIFT + CD-STB 3 Shift + 3 |
| TREBLE 3 TV | CD-STB 3 3 |
| 4 FM/AM | SHIFT + VIDEO 4 Shift + 4 |
| 4 TV | VIDEO 4 4 |
| BASS 5 FM/AM | SHIFT + TAPE 5 Shift + 5 |
| BASS 5 TV | TAPE 5 5 |
| TREBLE 6 FM/AM | SHIFT + TUNER 6 Shift + 6 |
| TREBLE 6 TV | TUNER 6 6 |
| 7 FM/AM | SHIFT + AUX-HDD 7 Shift + 7 |
| 7 TV | AUX-HDD 7 7 |
| 8 FM/AM | SHIFT + USB 8 Shift + 8 |
| 8 TV | USB 8 8 |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| 9 FM/AM | SHIFT + 9 | | |
| 9 TV | 9 | | |
| 10 FM/AM | SHIFT + FAV / Marker / PC | | |
| 10/Tv Return TV | SHIFT + 0 | | |
| 0 TV | 0 | | |
| +10/100+ | SHIFT + GUIDE EPG | | |
| +10 TV | FAV / Marker / PC | | |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Power DVD | Power | Audio | Audio / Lang I/II |
| I<< | I<< / Preset- | Subtitle | Subtitle / EQ |
| Play | Play / Slow | Title Group | Shift + Sound / Title |
| >>I | >>I / Preset+ | Return | Back / Return |
| << | << / Tune- | DVD Zoom | Zoom / Size |
| Stop | Stop / Hold | 1 | 1 |
| Pause | Pause / Step / Freeze | 2 | 2 |
| Top Menu | D. Menu / Top | 3 | 3 |
| >> | >> / Tune+ | VFP Progressive | Smart / List |
| Up | Up | 4 | 4 |
| Menu | Menu / Home | 5 | 5 |
| Left | Shift + Left | 6 | 6 |
| Enter | OK | ← | Left |
| Right | Right | 7 | 7 |
| Set Up | Setup / OPT / | 8 | 8 |
| Down | Down | 9 | 9 |
| On Screen | Shift + Display / Media | Angle | Info / Angle |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| TV RETURN 10 | 10 | GUIDE EPG | Guide / EPG / -/-- | | |
| 0 | 0 | HDMI - SAT 0 | 0 | | |
| 100+ +10 | +10 | PC FAV MARKER | Fav / Marker / PC | | |
| DIMMER | Display/Dimmer | MEDIA DISPLAY | Display / Media | | |
| ANALOG/DIGITAL INPUT | Input Analog/Digital | RDS AV INPUT | AV / Input / RDS | | |
| CANCEL | Cancel | CLEAR EXIT CANCEL | Exit / Cancel / Clear | | |
| EFFECT | HDD Sound Effect | TITLE SOUND | Sound / Title | | |
| SURROUND | Surround | SURROUND | Eject / Surround | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

| Original | Replacement |
|---|---|
| Power VCR | SHIFT + Power (Shift + Power) |
| Power STB | Power |
| VCR | SHIFT + GUIDE EPG (Shift + Guide / EPG / -/--) |
| Muting | DIMMER MUTE (Mute / Dimmer) |
| Channel + | CH+ / Page+ |
| Volume+ | Vol + |
| Channel - | CH- / Page- |
| Volume- | Vol - |
| Play VCR | SLOW (Play / Slow) |
| << VCR | TUNE- (<< / Tune-) |
| Stop/Memory | HOLD (Stop / Hold) |
| Pause VCR | STEP-FREEZE (Pause / Step / Freeze) |
| >> VCR | TUNE+ (>> / Tune+) |
| 1 VCR | SHIFT + TV 1 (Shift + 1) |
| 1 STB | TV 1 (1) |
| 2 VCR | SHIFT + DVD 2 (Shift + 2) |
| 2 STB | DVD 2 (2) |

| Original | Replacement |
|---|---|
| 3 VCR | SHIFT + CD-STB 3 (Shift + 3) |
| 3 STB | CD-STB 3 (3) |
| 4 VCR | SHIFT + VIDEO 4 (Shift + 4) |
| 4 STB | VIDEO 4 (4) |
| 5 VCR | SHIFT + TAPE 5 (Shift + 5) |
| 5 STB | TAPE 5 (5) |
| 6 VCR | SHIFT + TUNER 6 (Shift + 6) |
| 6 STB | TUNER 6 (6) |
| 7 VCR | SHIFT + AUX-HDD 7 (Shift + 7) |
| 7 STB | AUX-HDD 7 (7) |
| 8 VCR | SHIFT + USB 8 (Shift + 8) |
| 8 STB | USB 8 (8) |
| 9 VCR | SHIFT + BLUETOOTH 9 (Shift + 9) |
| 9 STB | BLUETOOTH 9 (9) |
| +10 TV | GUIDE EPG (Guide / EPG / -/--) |
| 0 VCR | SHIFT + HDMI-SAT 0 (Shift + 0) |
| 0 STB | HDMI-SAT 0 (0) |