Original		Replacement	
ON	Power On		Power
OFF	Power Off	SHIFT +	Shift + Power
DIMMER DIMM	Dimmer	DIMMER MUTE	Mute / Dimmer
OPEN / CLOSE	Open/Close	SURROUND	Eject / Surround
A-B REPEAT A-B	A-B Repeat	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
REPEAT	Repeat	SHIFT + APP REPEAT	Shift + Green / APP /
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
RANDOM RAND	Random	SHIFT + Prime Video RANDOM	Shift + Blue / Prime
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
ZOOM	Zoom	SIZE ZOOM	Zoom / Size

Original		Replacement	
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
0	0	HDMI - SAT 0	0
SRCH	Search Mode	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
RED	Red	NETFLIX SEARCH	Red / Netflix / Search
GRN	Green	APP REPEAT	Green / APP / Repeat
YEL	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
BLU	Blue	Prime Video RANDOM	Blue / Prime Video / Random
TOP MENU T	Top Menu	TOP MENU D.MENU	D.Menu / Top
	Up		Up
POP UP MENU/ MENU M	Pop Up Menu /	HOME MENU	Menu / Home
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
	Down		Down
SETUP S	Setup	OPT-TOOLS SETUP	Setup / OPT /
RETURN R	Return	RETURN BACK	Back / Return
ANGLE	Angle	ANGLE INFO	Info / Angle

Original		Replacement	
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
PURE DIRECT PURE.D	Pure Direct	TITLE SOUND	Sound / Title
DISPLAY	Display	MEDIA DISPLAY	Display / Media
MODE	Mode	LIST SMART	Smart / List
I<<	I<< Skip	PRESET- I<<	I<< / Preset-
>>I	Skip >>I	PRESET+ >>I	>>I / Preset+
STOP	Stop	HOLD	Stop / Hold
PLAY	Play	SLOW	Play / Slow
<<	<<	TUNE- <<	<< / Tune-
STILL/PAUSE	Still/Pause	STEP-FREEZE	Pause / Step / Freeze
>>	>>	TUNE+ >>	>> / Tune+
HDMI RESOLUTION	HDMI	FORMAT PICTURE	Picture / Format
INPUT ▲	Input Up Amp/Receiver	+ CH PAGE	CH+ / Page+
VOLUME +	Vol+	+ VOL	Vol+
▼	Input Down Amp/Receiver	CH PAGE −	CH- / Page-
−	Vol-	VOL −	Vol-

Original	Replacement