Mandis shop

Onkyo RC-707M RECEIVER

Original	Replacement	Original	Replacement
On / Standby	Power	CH/Disc/Album	Ch +
SP A/B	Media	CH/Disc/Album	Ch -
Menu	Menu	Up	Up
D.TUN	D. Menu	Left	Left
Display	Info	Enter	Ok
DVD	1	Right	Right
VCR / DVR	2	Down	Down
CBL/SAT	3	Setup	Options
CD	4	Return	Back
MULTI CH	5	Audio	Dual
AUX	6	I <<	I <<
TAPE	7	>>I	>>I
TUNER	8	<<	<<
DOCK	9	Play	Play
Muting	Mute	>>	>>
Vol +	Vol +	Pause/Play	Pause
Vol -	Vol -	Stop	Stop

Original		Replacement		Original	Replacement
MOVIE/TV SEARCH	Movie/TV	A	Red		
MUSIC REPEAT	Music	B	Green		
GAME RANDOM	Game	C	Yellow		
STEREO PLAY MODE	Stereo	D	Blue		
1	1	SHIFT + 1	Shift + 1		
2	2	SHIFT + 2	Shift + 2		
3	3	SHIFT + 3	Shift + 3		
4	4	SHIFT + 4	Shift + 4		
5	5	SHIFT + 5	Shift + 5		
6	6	SHIFT + 6	Shift + 6		
7	7	SHIFT + 7	Shift + 7		
8	8	SHIFT + 8	Shift + 8		
9	9	SHIFT + 9	Shift + 9		
0	0	0	0		
+10 DIMMER	Dimmer	HOME SMART	Smart		
CLR SLEEP	Sleep	PROG SLEEP	Sleep		