Original	Replacement	Original	Replacement
Power MD	Power	Up	Up
Direct Tuning	Text	Down	Down
Dimmer	Pre Ch	Right	Right
TV	TV/R	Left	Left
CD	Yellow	Enter	Ok
DVD	Blue	Menu	D. Menu
Tuner/Band	Green	Display	Info
Tape	Red	Top Menu/Disc/Deck	Menu
VCR	Smart	1 MD	1
MD	Media	2 MD	2
Vol +	Vol +	3 MD	3
Vol -	Vol -	4 MD	4
Muting	Mute	5 MD	5
Stop MD	Stop	6 MD	6
Play MD	Play	7 MD	7
<</I << MD	<<	8 MD	8
>>/>>I MD	>>	9 MD	9

Original		Replacement	
0	0 MD	0	0
≥10/-/--	>10/-/-- MD	-/-- GUIDE	Guide
TV/AV	Tv/AV	TIMER AV	AV
STEREO	Stereo	SOUND DUAL	Dual
SURROUND	Surround	SETTINGS OPT	Options
SFC	SFC	AD SUBT	Subt
TEST	Test	RETURN BACK	Back
DELAY	Delay	PICTURE FORMAT	Format
LEVEL	Level	ECO 3D	3D
+	+	+ CH	Ch +
-	-	CH −	Ch -
	Power TV	SHIFT +	Shift + Power
VOL ^	Tv Vol Up	SHIFT + + VOL	Shift + Vol +
TV v	Tv Vol Down	SHIFT + VOL −	Shift + Vol -
1	1 Tv	SHIFT + 1	Shift + 1
2	2 Tv	SHIFT + 2	Shift + 2
3	3 Tv	SHIFT + 3	Shift + 3

Original		Replacement	
4	4 Tv	SHIFT + 4	Shift + 4
5	5 Tv	SHIFT + 5	Shift + 5
6	6 Tv	SHIFT + 6	Shift + 6
7	7 Tv	SHIFT + 7	Shift + 7
8	8 Tv	SHIFT + 8	Shift + 8
9	9 Tv	SHIFT + 9	Shift + 9
0	0 Tv	SHIFT + 0	Shift + 0
≥10/-/--	>10/-/-- Tv	SHIFT + -/-- GUIDE	Shift + Guide

Original		Replacement	
	Power DVD		Power
TV	TV	SEARCH TV/R	TV/R
VCR	VCR	HOME SMART	Smart
TUNER/ BAND	Tuner/Band	B	Green
TAPE	Tape	A	Red
MD	MD	APP MEDIA	Media
CD	CD	C	Yellow
DVD	DVD	D	Blue
	Play DVD	PLAY MODE	Play
	I<</<< DVD		<<
	Stop DVD		Stop
	>>/>>I DVD		>>
TOP MENU DISC/DECK 1/2	Top Menu/Disc/Deck	TOP MENU MENU	Menu
DISPLAY	Display	DISPLAY INFO	Info
MENU	Menu	E-MANUAL D.MENU	D. Menu
	Up		Up
	Down		Down

Original		Replacement	
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
STEREO	Stereo	SOUND DUAL	Dual
SURROUND	Surround	SETTINGS OPT	Options
SFC	SFC	AD SUBT	Subt
TEST	Test	RETURN BACK	Back
DELAY	Delay	PICTURE FORMAT	Format
LEVEL	Level	ECO 3D	3D
+	+	+ CH	Ch +
-	-	CH -	Ch -
1	1 DVD	1	1
2	2 DVD	2	2
3	3 DVD	3	3
4	4 DVD	4	4
5	5 DVD	5	5
6	6 DVD	6	6

Original	Replacement	Original	Replacement
7 DVD	7		
8 DVD	8		
9 DVD	9		
0 DVD	0		
>10/ - / - - DVD	Guide		
Vol +	Vol +		
Vol -	Vol -		
Muting	Mute		

Original	Replacement	Original	Replacement
Power CD	Power	Right	Right
TV	TV/R	Left	Left
VCR	Smart	Enter	Ok
CD	Yellow	Stereo	Dual
DVD	Blue	Surround	Options
Tape	Red	SFC	Subt
MD	Media	Test	Back
Tuner/Band	Green	Delay	Format
Stop CD	Stop	Level	3D
I<</<< CD	<<	+	Ch +
>>/>>I CD	>>	-	Ch -
Play CD	Play	Vol +	Vol +
Menu	D. Menu	Vol -	Vol -
Display	Info	Muting	Mute
Top Menu/Disc/Deck	Menu	Power Tape	Shift + Power
Up	Up	Stop Tape	Shift + Stop
Down	Down	Play Tape	Shift + Play

Original		Replacement		Original	Replacement
I <</ << Tape		SHIFT + <<	Shift + <<		
>>/ >>I Tape		SHIFT + >>	Shift + >>		
Top Menu/ Disc/ Deck		SHIFT + TOP MENU / MENU	Shift + Menu		
1 CD- Tape		1	1		
2 CD- Tape		2	2		
3 CD- Tape		3	3		
4 CD- Tape		4	4		
5 CD- Tape		5	5		
6 CD- Tape		6	6		
7 CD- Tape		7	7		
8 CD- Tape		8	8		
9 CD- Tape		9	9		
0 CD- Tape		0	0		
>10/ - / - - CD- Tape		GUIDE	Guide		
Direct Tuning/ Disc Ente		REPEAT / TEXT	Text		

Original		Replacement	
	Power VCR		Power
DIMMER	Dimmer	FAV PRE-CH	Pre Ch
VCR	VCR	HOME SMART	Smart
TAPE	Tape	A	Red
TV	TV	SEARCH TV/R	TV/R
CD	CD	C	Yellow
DVD	DVD	D	Blue
TUNER/ BAND	Tuner/Band	B	Green
MD	MD	APP MEDIA	Media
	Stop		Stop
	I<</<<		<<
	>>/>>I		>>
	Play	PLAY MODE	Play
1	1 VCR	1	1
2	2 VCR	2	2
3	3 VCR	3	3
4	4 VCR	4	4

Original		Replacement	
5	5 VCR	5	5
6	6 VCR	6	6
7	7 VCR	7	7
8	8 VCR	8	8
9	9 VCR	9	9
0	0 VCR	0	0
≥10/-/--	>10/-/-- VCR	-/-- GUIDE	Guide
DIRECT TUNING DISC ENTER	Direct Tuning/Disc Ente	REPEAT TEXT	Text
VOL +	Vol +	+ VOL	Vol +
VOL -	Vol -	VOL -	Vol -
MUTING	Muting	MUTE	Mute
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
TOP MENU DISC/DECK 1/2	Top Menu/Disc/Deck	TOP MENU MENU	Menu

Original	Replacement
Display	Info
Menu	D. Menu
Stereo	Dual
Surround	Options
SFC	Subt
Test	Back
Delay	Format
Level	3D
+	Ch +
-	Ch -
Power Tuner / Band	Shift + Power
1 Tuner / Band	Shift + 1
2 Tuner / Band	Shift + 2
3 Tuner / Band	Shift + 3
4 Tuner / Band	Shift + 4
5 Tuner / Band	Shift + 5
6 Tuner / Band	Shift + 6

Original	Replacement
7 Tuner / Band	Shift + 7
8 Tuner / Band	Shift + 8
9 Tuner / Band	Shift + 9
0 Tuner / Band	Shift + 0
>10/-/--	Shift + Guide