Mandis shop

BOSE ROOMMATE

Original		Replacement	
On / Off	On / Off		Power
Mute / Mute All	Mute / Mute All	DIMMER MUTE	Mute / Dimmer
	Up		Up
	Left		Left
	OK	OK	OK
	Right		Right
	Down		Down
	I<<	PRESET-	I<< / Preset-
Volume	Volume+	VOL	Vol+
Volume	Volume-	VOL	Vol-
	>>I	PRESET+	>>I / Preset+
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
Shuffle-Repeat	Shuffle	Prime Video RANDOM	Blue / Prime Video / Random
Shuffle-Repeat	Repeat	APP REPEAT	Green / APP / Repeat
Playlist	Playlist	LIST SMART	Smart / List

Original		Replacement	
Setup	Setup	OPT-TOOLS SETUP	Setup / OPT /

https://all-remotes.online/en/BOSE/1062351-93729-replacement-remote-control-for-BOSE-ROOMMATE.html