Original		Replacement	
POWER	Power		Power
	Mute	MUTE	Mute
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
CH LIST	CH List	DISC NAV LIST	List
BACK RETURN	Return / Back	RETURN BACK	Back
MENU	Menu	TOP MENU MENU	Menu
SOURCE	Source	TIMER AV	AV
	Home	HOME SMART	Smart

Original		Replacement	
EXIT	Exit / Setting	CLEAR EXIT	Exit
You Tube	YouTube	APP MEDIA	Media
+ VOL	Vol +	+ VOL	Vol +
VOL −	Vol -	VOL −	Vol -
INFO	Info	DISPLAY INFO	Info
EPG	EPG	-/-- GUIDE	Guide
PR	PR+	+ CH	Ch +
PR	PR-	CH −	Ch -
	Up		Up
	Left		Left
OK	OK	OK	Ok
	Right		Right
	Down		Down
REC	Rec	REC MODE	Rec
NICAM/I/II	Nicam / I/II	SOUND DUAL	Dual
TEXT	Text	REPEAT TEXT	Text
SUB-PAGE AD	AD / Sub-Page	AD SUBT	Subt

Original		Replacement		Original	Replacement
SIZE FAV	FAV / Size	FAV PRE-CH	Pre Ch		
HOLD QUICK	Quick / Hold / Freeze	SHIFT +	Shift + Stop		
	Red	A	Red		
	Green	B	Green		
	Yellow	C	Yellow		
	Blue	D	Blue		
INDEX	Play/Pause / Ind	PLAY MODE	Play		
INDEX	Play/Pause / Ind		Pause		
REVEAL	<< / Reveal		<<		
MIX	>> / Mix		>>		
CANCEL	Stop / Cancel		Stop		