Mandis shop

GYM001

Original		Replacement		Original	Replacement
	Power		Power		
START/STOP	Start/Stop	PLAY MODE	Play		
+ SPEED	Speed+		Up		
- SPEED	Speed-		Down		
TIME-	Time-		Left		
TIME+	Time+		Right		
P PROGRAM	Program	HOME SMART	Smart		
M MANUAL	Manual	APP MEDIA	Media		

https://all-remotes.online/en/Gym-Form/1063091-92940-replacement-remote-control-for-Gym-Form-GYM001.html