Mandis shop

LG AKB75375609

Original	Replacement	Original	Replacement
Power	Power	Q. View	Display / Media
Tv/ Rad	TV/ Radio /	Vol +	Vol +
Subtitle	Subtitle / EQ	FAV	Fav / Marker / PC
AD	Audio / Lang I/II	P+	CH+ / Page+
Ratio	Picture / Format	Vol -	Vol -
Input	AV / Input / RDS	Guide	Guide / EPG / -/--
1	1	P-	CH- / Page-
2	2	Mute	Mute / Dimmer
3	3	Text	Text / Goto
4	4	Home	Smart / List
5	5	T. Opt.	Setup / OPT /
6	6	Settings	Menu / Home
7	7	Up	Up
8	8	Q. Menu	D. Menu / Top
9	9	Left	Left
List	Shift + Smart / List	OK	OK
0	0	Right	Right

Original		Replacement		Original	Replacement
BACK	Back	RETURN BACK	Back / Return		
	Down		Down		
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
INFO	Info	ANGLE INFO	Info / Angle		
REC/*	Rec	REC MODE	Rec / Rec Mode		
■	Stop	HOLD ■	Stop / Hold		
<<	<<	TUNE- <<	<< / Tune-		
▶	Play	SLOW ▶	Play / Slow		
❚❚	Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze		
>>	>>	TUNE+ >>	>> / Tune+		
●	Red	NETFLIX SEARCH	Red / Netflix / Search		
●●	Green	APP REPEAT	Green / APP / Repeat		
●●●	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
●●●●	Blue	Prime Video RANDOM	Blue / Prime Video / Random		