Original	Replacement	Original	Replacement
On/Off	Power	OK Enter	Ok
Mute	Mute	Menu Right	Right
Update	Play	Menu Off	Exit
Reveal	Pause	Menu Down	Down
Txt Stop	Stop	Back	Back
Info	List	Volume+	Vol +
Subt. List	Subt	Chan. Up	Ch +
Sleep Timer	Sleep	Volume-	Vol -
Return TV	TV/R	Menu audio	Dual
Menu video	D. Menu	Chan. Down	Ch -
Text	Text	1	1
Txt Expand	Eject	2	2
TV/AV	AV	3	3
Menu	Menu	4	4
Menu Up	Up	5	5
Display	Info	6	6
Menu Left	Left	7	7

Original	Replacement
8	8
9	9
Guide -/-- 1.	GUIDE
0/10	0
2. Fav P/C 2.	FAV PRE-CH
Red	A
Green	B
Yellow	C
Blue	D
Audio-	<<
Audio+	>>
Mix Scan	APP MEDIA
AV 2	SHIFT + TIMER AV (Shift + AV)
Tone+	SETTINGS OPT
Bright+ Mode	SHIFT + TOP MENU MENU (Shift + Menu)
Search	SHIFT + SEARCH TV/R (Shift + TV/R)
Tune-	I <<

Original	Replacement
Tune+	>>I
Aft/Caf	SHIFT + OK (Shift + Ok)
Store	HOME SMART
Bright- Sys	SHIFT + CLEAR EXIT (Shift + Exit)
Color- S.Std	SHIFT + SOUND DUAL (Shift + Dual)
Surround	SHIFT + A (Shift + Red)
Nicam/Mono	SHIFT + B (Shift + Green)
Level L	SHIFT + C (Shift + Yellow)

Original	Replacement	Original	Replacement
On/Off	Power	OK Enter	Ok
Mute	Mute	Menu Right	Right
Update	Play	Menu Off	Exit
Reveal	Pause	Menu Down	Down
Txt Stop	Stop	Back	Back
Info	List	Volume+	Vol +
Subt. List	Subt	Chan. Up	Ch +
Sleep Timer	Sleep	Volume-	Vol -
Return TV	TV/R	Menu audio	Dual
Menu video	D. Menu	Chan. Down	Ch -
Text	Text	1	1
Txt Expand	Eject	2	2
TV/AV	AV	3	3
Menu	Menu	4	4
Menu Up	Up	5	5
Display	Info	6	6
Menu Left	Left	7	7

Original	Replacement	Original	Replacement
8	8		
9	9		
Guide -/-- 1.	GUIDE		
0/10	0		
2. Fav P/C 2.	FAV PRE-CH		
Red	A		
Green	B		
Yellow	C		
Blue	D		
Mix Scan	SHIFT + SEARCH TV/R		
Disp	SHIFT + DISPLAY INFO		