Original		Replacement	
	Power		Power
	Sleep	TIMER SLEEP	Sleep / Timer
	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	I-II	LANG I/II AUDIO	Audio / Lang I/II
	I.S.	MEDIA DISPLAY	Display / Media
	i+	ANGLE INFO	Info / Angle
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
SMART	Smart Picture	FORMAT PICTURE	Picture / Format

Original		Replacement	
SMART	Smart Audio	TITLE SOUND	Sound / Title
MENU	Menu	HOME MENU	Menu / Home
OK	Text / OK	GOTO TEXT	Text / Goto
OK	Text / OK	OK	OK
	Up		Up
	Left		Left
	Right		Right
	Down		Down
	Vol +	VOL +	Vol +
	Vol -	VOL −	Vol -
	Mute	DIMMER MUTE	Mute / Dimmer
P	P+	CH PAGE +	CH+ / Page+
P	P-	CH PAGE −	CH- / Page-
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random

Original	Replacement
RADIO TV/ Radio	PROGRAM TV/ RADIO TV/ Radio /
Hold	HOLD Stop / Hold
Size	SIZE ZOOM Zoom / Size
Mix	SHIFT + GOTO TEXT Shift + Text /
Light	LIST SMART Smart / List
?	STEP-FREEZE Pause / Step / Freeze
ON/OFF Alarm On/Off	SHIFT + TV 1 Shift + 1
SET ALARM Alarm Set	SHIFT + DVD 2 Shift + 2
RESET Alarm Reset	SHIFT + CD-STB 3 Shift + 3

Original	Replacement