Original		Replacement	
POWER	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
-/--	-/--/[=+]	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI-SAT 0	0
PRE-CH	PRE-CH	RETURN BACK	Back / Return
	Vol +	+ VOL	Vol +
P	P+	+ CH PAGE	CH+ / Page+
VIDEO	Video/[=_]	RDS AV INPUT	AV / Input / RDS
MUTE	Mute	DIMMER MUTE	Mute / Dimmer

Original		Replacement	
	Vol -	VOL –	Vol -
	P-	CH PAGE –	CH- / Page-
MENU	Menu/[=i]	HOME MENU	Menu / Home
TV	TV	PROGRAM TV/RADIO	TV/Radio /
INFO	Info/[=?]	ANGLE INFO	Info / Angle
	Up	▲	Up
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Left	◀	Left
ENTER	Enter	OK	OK
	Right	▶	Right
	Down	▼	Down
TTX/MIX	[=]TTX/MIX	GOTO TEXT	Text / Goto
	[=o]	LANG I/II AUDIO	Audio / Lang I/II
P.SIZE	[=♦]/P.Size/[<>]	SIZE ZOOM	Zoom / Size
SLEEP	[=♦]/Sleep/Timer	TIMER SLEEP	Sleep / Timer
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat

Original	Replacement	Original	Replacement
Yellow	Yellow / YouTube / Repeat		
Blue/ P. Mode	Blue / Prime Video / Random		