Mandis shop

Scott SW20RC

Original		Replacement	
FUNCTION	Function	HOME MENU	Menu / Home
POWER STANDBY	Power/Standby		Power
STOP/ BAND	Stop/Band	HOLD	Stop / Hold
PLAY / PAUSE	Play	SLOW	Play / Slow
PLAY / PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
R-SKIP/ DOWN	I<<	PRESET-	I<< / Preset-
F-SKIP/ UP	>>I F.Skip/Up	PRESET+	>>I / Preset+
-10 TRACK PRESET DN.	-10 Track/Down		Left
+10 TRACK PRESET UP	+10 Track		Right
FOLDER DOWN	Folder Down		Down
FOLDER UP	Folder Up		Up
CLOCK-ADJ/ MEMORY	Clock Adj/Memory	OPT-TOOLS SETUP	Setup / OPT /
M-UP/ PLAY MODE	M-Up/Play Mode	LIST SMART	Smart / List
ID3	ID3	RDS AV INPUT	AV / Input / RDS
TIMER/ SLEEP	Timer/Sleep	TIMER SLEEP	Sleep / Timer
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
PRESET EQ	Preset EQ	MEDIA DISPLAY	Display / Media

Original		Replacement	
VOL-	Vol-	VOL	Vol-
VOL+	Vol+	VOL	Vol+

https://all-remotes.online/en/Scott/1066579-82179-replacement-remote-control-for-Scott-SW20RC.html