Mandis shop

Sony RMT-708

Original		Replacement		Original	Replacement
PLAY	Play	SLOW ▶	Play / Slow		
START/STOP	Start/Stop	⏻	Power		
START/STOP	Start/Stop	REC MODE ●	Rec / Rec Mode		
REW ◀◀	<<	TUNE- ◀◀	<< / Tune-		
FF ▶▶	>>	TUNE+ ▶▶	>> / Tune+		
STOP	Stop	HOLD ■	Stop / Hold		
	T	+ CH PAGE	CH+ / Page+		
PAUSE	Pause	STEP-FREEZE ⏸	Pause / Step / Freeze		
SLOW	I>/Slow	▶	Right		
SLOW	I>/Slow	SHIFT + SLOW ▶	Shift + Play /		
	W	CH PAGE −	CH- / Page-		
DISPLAY	Display	MEDIA DISPLAY	Display / Media		

https://all-remotes.online/en/Sony/1068047-6337-replacement-remote-control-for-Sony-RMT-708-146757423.html