Original	Replacement
Power	Power
Mute	Mute / Dimmer
Play	Play / Slow
Stop	Stop / Hold
Rec	Rec / Rec Mode
<<	<< / Tune-
>>	>> / Tune+
[<>]	Picture / Format
>I <	D. Menu / Top
[1I 2]	Setup / OPT /
[≡]	Text / Goto
Source	AV / Input / RDS
Menu	Menu / Home
Up	Up
[i +]	Info / Angle
Left	Left
OK	OK

Original	Replacement
Right	Right
Down	Down
Vol +	Vol +
[-O-] / Active Control	Smart / List
P+	CH+ / Page+
Vol -	Vol -
P-	CH- / Page-
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
Guide	Guide / EPG / -/--

Original	Replacement
0	0
P<P	Fav / Marker / PC
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
Power AMP	Shift + Power
Mute AMP	Shift + Mute / Dimmer
<< AMP	Shift + << /
>> AMP	Shift + >> /
[≡] AMP	Shift + Text /
Menu AMP	Shift + Menu /
Up AMP	Shift + Up
Left AMP	Shift + Left
OK AMP	Shift + OK
Right AMP	Shift + Right
Down AMP	Shift + Down

Original	Replacement
Vol + AMP	Shift + Vol +
P+ AMP	Shift + CH+ /
Vol - AMP	Shift + Vol -
P- AMP	Shift + CH- /
1 AMP	Shift + 1
2 AMP	Shift + 2
3 AMP	Shift + 3
4 AMP	Shift + 4
5 AMP	Shift + 5
6 AMP	Shift + 6
7 AMP	Shift + 7
8 AMP	Shift + 8
9 AMP	Shift + 9
Guide AMP	Shift + Guide / EPG / -/--
0 AMP	Shift + 0
P<P AMP	Shift + Fav / Marker / PC

Original	Replacement	Original	Replacement
Power	Power	P-	CH- / Page-
Guide	Guide / EPG / -/--	1	1
Source	AV / Input / RDS	2	2
>I<	D. Menu / Top	3	3
[1I2]	Setup / OPT /	4	4
[i+]	Info / Angle	5	5
Up	Up	6	6
Left	Left	7	7
OK	OK	8	8
Right	Right	9	9
Down	Down	0	0
[≡]	Text / Goto	P<P	Fav / Marker / PC
Menu	Menu / Home	<<	<< / Tune-
Vol +	Vol +	Stop	Stop / Hold
Mute	Mute / Dimmer	Play	Play / Slow
P+	CH+ / Page+	>>	>> / Tune+
Vol -	Vol -	[<>]	Picture / Format

Original	Replacement	Original	Replacement
[-O-]/Active Control	Smart / List		

Original	Replacement
Power	Power
Mute	Mute / Dimmer
Play	Play / Slow
Stop	Stop / Hold
Rec	Rec / Rec Mode
<<	<< / Tune-
>>	>> / Tune+
[<>]	Picture / Format
>I <	D. Menu / Top
[1I 2]	Setup / OPT /
Source	AV / Input / RDS
Menu	Menu / Home
Up	Up
[i +]	Info / Angle
Left	Left
OK	OK
Right	Right

Original	Replacement
Down	Down
Vol +	Vol +
[-O-] / Active Control	Smart / List
P+	CH+ / Page+
Vol -	Vol -
P-	CH- / Page-
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
P<P	Fav / Marker / PC

Original	Replacement
Red	NETFLIX SEARCH — Red / Netflix / Search
Green	APP REPEAT — Green / APP / Repeat
Yellow	YouTube REPEAT A-B — Yellow / YouTube / Repeat
Blue	Prime Video RANDOM — Blue / Prime Video / Random
Power VCR	SHIFT + Power — Shift + Power
Play VCR	SHIFT + SLOW — Shift + Play /
Stop VCR	SHIFT + HOLD — Shift + Stop /
Rec VCR	SHIFT + REC MODE — Shift + Rec / Rec Mode
<< VCR	SHIFT + TUNE- — Shift + << /
>> VCR	SHIFT + TUNE+ — Shift + >> /
>I < VCR	SHIFT + TOP MENU D.MENU — Shift + D.Menu / Top Menu
Source VCR	SHIFT + RDS AV INPUT — Shift + AV / Input / RDS
Menu VCR	SHIFT + HOME MENU — Shift + Menu /
Up VCR	SHIFT + ▲ — Shift + Up
[i+] VCR	SHIFT + ANGLE INFO — Shift + Info / Angle
Left VCR	SHIFT + ◀ — Shift + Left
OK VCR	SHIFT + OK — Shift + OK

Original	Replacement
Right VCR	SHIFT + ▶ — Shift + Right
Down VCR	SHIFT + ▼ — Shift + Down
P+ VCR	SHIFT + CH PAGE + — Shift + CH+ /
P- VCR	SHIFT + CH PAGE − — Shift + CH- /
1 VCR	SHIFT + TV 1 — Shift + 1
2 VCR	SHIFT + DVD 2 — Shift + 2
3 VCR	SHIFT + CD-STB 3 — Shift + 3
4 VCR	SHIFT + VIDEO 4 — Shift + 4
5 VCR	SHIFT + TAPE 5 — Shift + 5
6 VCR	SHIFT + TUNER 6 — Shift + 6
7 VCR	SHIFT + AUX-HDD 7 — Shift + 7
8 VCR	SHIFT + USB 8 — Shift + 8
9 VCR	SHIFT + BLUETOOTH 9 — Shift + 9
0 VCR	SHIFT + HDMI-SAT 0 — Shift + 0
P<P VCR	SHIFT + PC FAV MARKER — Shift + Fav / Marker / PC

Original		Replacement	
	Power		Power
	Guide		Guide / EPG / -/--
	>I <		D. Menu / Top
	[i +]		Info / Angle
	Up		Up
	Left		Left
	Right		Right
	Down		Down
	Vol +		Vol +
	Mute		Mute / Dimmer
	P+		CH+ / Page+
	Vol -		Vol -
	P-		CH- / Page-
	1		1
	2		2
	3		3
	4		4

Original		Replacement	
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	P<P		Fav / Marker / PC
	<<		<< / Tune-
	Stop		Stop / Hold
	Play		Play / Slow
	>>		>> / Tune+