| Original | | Replacement | |
|---|---|---|---|
| POWER | Power | | Power |
| TV/RADIO | Eject | SURROUND | Eject / Surround |
| TV/RADIO | Tv/Radio | PROGRAM TV/RADIO | TV/Radio / |
| GOTO | Red/Goto | NETFLIX SEARCH | Red / Netflix / Search |
| GOTO | Red/Goto | SHIFT + GOTO TEXT | Shift + Text / |
| ANGLE | Green/Angle | ANGLE INFO | Info / Angle |
| ANGLE | Green/Angle | APP REPEAT | Green / APP / Repeat |
| REPEAT | Yellow/Repeat | SHIFT + APP REPEAT | Shift + Green / APP / |
| REPEAT | Yellow/Repeat | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| A-B | Blue/A-B | SHIFT + Prime Video RANDOM | Shift + Blue / Prime |
| A-B | Blue/A-B | Prime Video RANDOM | Blue / Prime Video / Random |
| FAV | FAV | PC FAV MARKER | Fav / Marker / PC |
| TEXT | Text | GOTO TEXT | Text / Goto |
| HOLD FREEZE | Freeze/Hold | SHIFT + HOLD | Shift + Stop / |
| HOLD FREEZE | Freeze/Hold | SHIFT + STEP-FREEZE | Shift + Pause / Step / |
| EPG D.MENU | EPG | -/-- GUIDE EPG | Guide / EPG / -/-- |
| EPG D.MENU | D.Menu | TOP MENU D.MENU | D.Menu / Top Menu |

| Original | | Replacement | |
|---|---|---|---|
| SUBTITLE | Subtitle | EQ SUBTITLE | Subtitle / EQ |
| SIZE ZOOM | Zoom/Size | SIZE ZOOM | Zoom / Size |
| ASPECT | Aspect | SHIFT + FORMAT PICTURE | Shift + Picture / Format |
| SUBPAGE | Subpage | SHIFT + EQ SUBTITLE | Shift + Subtitle / EQ |
| MEDIA | Media | SHIFT + MEDIA DISPLAY | Shift + Display / Media |
| ▶II | Play | SLOW ▶ | Play / Slow |
| ▶II | Pause | STEP-FREEZE II | Pause / Step / Freeze |
| ◀◀ | << | TUNE- ◀◀ | << / Tune- |
| ▶▶ | >> | TUNE+ ▶▶ | >> / Tune+ |
| D.SETUP | Rec | REC MODE | Rec / Rec Mode |
| D.SETUP | D.Setup | OPT-TOOLS SETUP | Setup / OPT / |
| ■ | Stop | HOLD ■ | Stop / Hold |
| I◀◀ | I<< | PRESET- I◀◀ | I<< / Preset- |
| INDEX ▶▶I | >>I/Index | PRESET+ ▶▶I | >>I / Preset+ |
| INDEX ▶▶I | >>I/Index | LIST SMART | Smart / List |
| MENU | Menu | HOME MENU | Menu / Home |
| LANG AUDIO | Lang/Audio | LANG I/II AUDIO | Audio / Lang I/II |

| Original | | Replacement | |
|---|---|---|---|
| | Up | | Up |
| | Left | | Left |
| OK | OK | OK | OK |
| | Right | | Right |
| SLEEP | Sleep | TIMER SLEEP | Sleep / Timer |
| | Down | | Down |
| EXIT TITLE | Title/Exit | SHIFT + TITLE SOUND | Shift + Sound / Title |
| EXIT TITLE | Title/Exit | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| + VOL | Vol + | + VOL | Vol + |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| + CH | CH+ | + CH PAGE | CH+ / Page+ |
| VOL − | Vol - | VOL − | Vol - |
| DISPLAY | Display | MEDIA DISPLAY | Display / Media |
| CH − | CH- | CH PAGE − | CH- / Page- |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD - STB 3 | 3 |

| Original | | Replacement | |
|---|---|---|---|
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX - HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| -/-- | -/-- | SHIFT + -/-- GUIDE EPG | Shift + Guide / EPG / -/-- |
| 0 | 0 | HDMI - SAT 0 | 0 |
| | Recall | RETURN BACK | Back / Return |
| SOURCE | Source | RDS AV INPUT | AV / Input / RDS |
| P-MODE | P. Mode | FORMAT PICTURE | Picture / Format |
| S-MODE | S. Mode | TITLE SOUND | Sound / Title |