Original		Replacement	
	Power		Power
	Mute		Mute / Dimmer
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
	Lang		Audio / Lang I/II
0	0	0	0
	Recall		Back / Return
	Vol +		Vol +
	Setting		Setup / OPT /
P	P+	CH	CH+ / Page+

Original		Replacement	
	Vol -	VOL	Vol -
HDMI	HDMI	SHIFT + 0	Shift + 0
P	P-	CH PAGE	CH- / Page-
	Media	SHIFT + DISPLAY	Shift + Display / Media
PMODE	P. Mode	FORMAT PICTURE	Picture / Format
HOME	Home	SHIFT + MENU	Shift + Menu /
SMODE	S. Mode	TITLE SOUND	Sound / Title
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
DISPLAY	Display	MEDIA DISPLAY	Display / Media
	Down		Down
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Red	NETFLIX SEARCH	Red / Netflix / Search

Original		Replacement		Original		Replacement	
SUB.T	Green	APP / REPEAT	Green / APP / Repeat				
SUB.T	Sub. T	EQ / SUBTITLE	Subtitle / EQ				
	Yellow	YouTube / REPEAT A-B	Yellow / YouTube / Repeat				
MOUSE	Blue/Mouse	Prime Video / RANDOM	Blue / Prime Video / Random				
⏯	Play	SLOW / ▶	Play / Slow				
⏯	Pause	STEP-FREEZE / ⏸	Pause / Step / Freeze				
■	Stop	HOLD / ■	Stop / Hold				
◀◀	<<	TUNE- / ◀◀	<< / Tune-				
▶▶	>>	TUNE+ / ▶▶	>> / Tune+				
⏮	I<<	PRESET- / ⏮	I<< / Preset-				
⏭	>>I	PRESET+ / ⏭	>>I / Preset+				
REC	Rec	REC MODE / ●	Rec / Rec Mode				