Original		Replacement	
Power		Power	
Mute		Mute	
Up		Up	
Down		Down	
Right		Right	
Left		Left	
OK/Select		Ok	
M		Menu	
1		1	
2		2	
3		3	
4		4	
5		5	
6		6	
7		7	
8		8	
9		9	

Original		Replacement	
0		0	
-/--/EXIT		-/--	Guide
-/--/EXIT		Exit	
P<P/SWAP		P<P/Swap	
Vol +		Vol +	
Vol -		Vol -	
P+		Ch +	
P-		Ch -	
PP		Eject	
I-II		I-II	Dual
TV/DTV		TV/R	
[≡]		Text	
[≡O]		Options	
AV/Source		AV	
[≡+] / [X]		Format	
[≡X] / [■■]		3D	
[. ≡] / [■]		Subt	

Original	Replacement	Original	Replacement
[≡♦]	Media		
[≡?]	Back		
[≡i]	Info		
Red/ [+] / Wide/ ↑	Red		
Green/ ↓	Green		
Yellow	Yellow		
Blue/ Guide	Blue		
[i]	D. Menu		